

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Obsah balení



Internetová kamera (1×)



Kabel USB (1×)



Napájecí adaptér (1×)



Pěnová
samolepka (2×)



Kovová destička
(1×) (průměr otvoru
3,5 mm)





Právní
informace
(1×)



Stručná
příručka
(1×)

i Vzhled kamery závisí na aktuálním zakoupeném modelu.

Popis



Název

Popis

Indikátor LED

- Nepřerušovaná červená: Kamera se spouští.
- Pomalu blikající červená: Připojení k síti Wi-Fi se nezdařilo.
- Rychle blikající červená: Došlo k výjimce zařízení (např. k chybě karty microSD).
- Nepřerušovaná modrá: Zobrazuje se video nebo dochází k přehrávání v aplikaci EZVIZ.
- Rychle blikající modrá: Kamera je připravena k připojení k síti Wi-Fi.
- Pomalu blikající modrá: Kamera je spuštěna a funguje správně.

Karta microSD

Kartu microSD je nutné zakoupit samostatně. Než začnete kartu používat, inicializujte ji v aplikaci EZVIZ.


Tlačítko
RESETOVÁNÍ

Stisknutím a podržením tlačítka RESETOVAT po dobu 5 sekund během provozu kamery se kamera restartuje a obnoví se výchozí nastavení všech parametrů kamery.

Instalace

Krok 1 Zapnutí

Připojte napájecí kabel ke kameře a k napájecímu adaptéru a poté jej zapojte do elektrické zásuvky. Viz níže uvedený obrázek.



Krok 2 Nastavení kamery


1. Vytvořte si uživatelský účet



- Připojte mobilní telefon k síti Wi-Fi.
- Zadáním textu „EZVIZ“ vyhledejte v obchodech App Store nebo Google Play™ aplikaci EZVIZ. Stáhněte ji a nainstalujte.
- Spusťte aplikaci. Postupujte podle pokynů průvodce prvním spuštěním a zaregistrujte svůj uživatelský účet EZVIZ.


2. Přidejte kameru do aplikace EZVIZ

- Přihlaste se do aplikace EZVIZ.
- Na domovské obrazovce aplikace EZVIZ stiskněte „+“ v pravém horním rohu a přejděte do rozhraní pro skenování kódu QR.



- Naskenujte kód QR na spodní části kamery.

Spodní část kamery



- Postupujte podle průvodce aplikace EZVIZ a dokončete konfiguraci sítě Wi-Fi.

i Zkontrolujte, že je telefon ke konfiguraci sítě Wi-Fi připojen k 2,4GHz síti Wi-Fi ze směrovače.

Montáž


Krok 1 Montáž kovové destičky (volitelná)

Vyberte čistý a rovný povrch a pomocí pěnových samolepek nebo šroubů (nejsou součástí dodávky) připevněte kovovou destičku do požadované polohy.

- i** Uvnitř kamery se nachází magnetický díl. Pokud je povrch z kovéhoho materiálu, můžete tento krok přeskočit.

Krok 2 Montáž kamery

Připevněte kameru magneticky ke kovové destičce nebo kovovému povrchu (viz obrázek níže).




Krok 3 Dokončení montáže

Nastavte požadovaný úhel kamery.

Dodatek


Vložte paměťovou kartu

Vložte do slotu kartu microSD, dokud nezapadne.



Inicializace paměťové karty

1. Zkontrolujte v aplikaci EZVIZ stav paměťové karty klepnutím na možnost **Storage Status (Stav úložiště)** v okně **Device Settings (Nastavení zařízení)**.

Wi-Fi Configure	TEST-WiFi  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. Pokud se stav paměťové karty zobrazí jako **Uninitialized (Neinicializovaný)**, klepnutím ji inicializujte. Stav se poté změní na hodnotu **Normal (Normální)**.



Podrobné informace naleznete na webových stránkách www.ezvizlife.com.