COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

#### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ \*\* website (http://www.ezvizlife.com).

Revision Record

New release - January, 2019

Trademarks Acknowledgement

EZVIZ<sup>™</sup>, \$\sqrt{2} \sqrt{1}, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL. CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS. BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT. EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT. F7VIZ DOES NOT LINDERTAKE ANY LIABILITY FOR PERSONAL INJURY

OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION

OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS: C) FORCE MAJEURE: D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS, REGARDING TO THE PRODUCT WITH INTERNET ACCESS.

THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS: HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION, PLEASE


CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION REFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW, EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW. THE LATTER PREVAILS.

# 박스 내용물



카메라 외관은 구매한 실제 제품에 따라 다를 수 있습니다.

# 기본 사항



#### 이름 설명

- LED 표시등 빨간색 켜짐: 카메라가 시작 중입니다.
  - 빨간색으로 천천히 깜박임: Wi-Fi 연결에 실패했습니다.
  - 빨간색으로 빠르게 깜박임: 장비 비정상 (예: microSD 카드 오류).
  - 파란색 켜짐: EZVIZ 앱에서 비디오를 보고 있거나 재생 줒입니다. • 파란색으로 빠르게 깜박임 : 카메라에 Wi-Fi 를 연결함
  - 준비가 되었습니다.
  - 파란색으로 천천히 깜박임 : 카메라가 올바르게 작동 줒입니다.
- microSD 카드 microSD 카드는 별도로 구매해야 합니다. 사용하기 전에 EZVIZ 앤에서 카드를 초기화하십시오.
- 초기화 버튼 카메라가 작동 중일 때 초기화 버튼을 5초 동안 누릅니다. 그러면 카메라가 다시 시작되고 모든 매개변수가 기보값으로 초기화된니다.

## 설정

### 1 단계 전원 켜기

아래 그림과 같이 전원 케이블을 카메라와 전원 어댑터에 연결한 후 전워 콘센트에 꽂습니다.



### 2 단계카메라 설정

- 1. 사용자 계정 생성
  - 모바일 폰을 Wi-Fi 에 연결합니다.
  - 앱 스토어 또는 구글 플레이 ™ 에서 "EZVIZ"를 검색하여 EZVIZ
  - 앱을 다운로드하고 설치하십시오.
  - 앱을 실행하여 다음의 시작 마법사에 따라 EZVIZ 사용자 계정을 등록합니다.
  - 2.EZVIZ 에 카메라를 추가합니다 . 🎎

    - EZVIZ 앤에 로그인합니다.
    - EZVIZ 앱 홈 화면의 오른쪽 구석 상단에 있는 "+"를 눌러 QR 코드 스캔 인터페이스로 이동하십시오.



- 카메라 바닥에 있는 QR 코드를 스캔합니다.



- EZVIZ 앱 마법사를 따라 Wi-Fi 구성을 완료하십시오.

- Wi-Fi 를 구성하기위해휴대전화가라우터의
  2.4GHz Wi-Fi에 연결되어있는지확인해주십시오.
- 이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역은 물론 모든 지역에서 사용할 수 있습니다. 위와 같은 무선설비는 전파혼선의 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.

### 설치


### 1 단계 금속판 설치 (선택 사항)

깨끗하고 평평한 표면을 선택한 다음 발포 스티커 또는 나사(미포한)를 사용해 금속판을 위하는 위치에 고정합니다.

i 카메라에 자석이 내장되어 있습니다. 표면이 금속성일 경우 이 단계를 생략할 수 있습니다.

### 2 단계 카메라 설치

카메라를 금속판 또는 금속 표면에 자기로 고정합니다 (아래 그림 참조).



### 3 단계 설치 마무리

필요에 따라 카메라 각도를 조정합니다.

### 부록

#### 메모리 카드 설치

microSD 카드를 딸깍 소리가 들릴 때까지 슬롯에 삽입합니다.



### 메모리 카드 초기화

1.EZVIZ 앱에서 Device Settings( 장비 설정) 인터페이스의 Storage Status( 저장소 상태)를 탭하여 메모리 카드 상태를 확인합니다.

Wi-Fi Configure	TEST-WiFi 🙃 →
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

- 2.메모리 카드 상태가 Uninitialized(초기화되지 않음)로 표시되면 탭하여 초기화합니다. 그러면 상태가 Normal(정상)으로 변경됩니다.
  - 🚺 자세한 정보를 알아보시려면 www.ezvizlife.com 을 방문해 주십시오 .