

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Inhoud van de doos



Internet camera (x1)



USB kabel (x1)



Voedingsadapter (x1)



Schuimsticker
(x2)



Metalen plaat (x1)
(diameter gat 3,5
mm)





Informatie met
betrekking tot
regelgeving (x1)



Snelstartgids
(x1)

i Het uiterlijk van de camera is onder voorbehoud van degene die u feitelijk hebt gekocht.

Algemeen




Naam **Omschrijving**

LED-indicator	<ul style="list-style-type: none">• Constant rood: Camera start op.• Knippert langzaam rood: Wifi-verbinding is mislukt.• Knippert snel rood: Uitzondering apparaat (bijv. fout micro-SD-kaart).• Constant blauw: Video wordt bekeken of afgespeeld in de EZVIZ-app.• Knippert snel blauw: Camera is gereed voor Wifi-verbinding.• Knippert langzaam blauw: Camera werkt correct.
microSD-kaart	micro-SD-kaart moet afzonderlijk worden aangeschaft. Initialiseer de kaart in de EZVIZ-app voordat u deze gebruikt.
Resetknop	Houd bij draaiende camera de toets HERSTELLEN gedurende 5 seconden ingedrukt; de camera herstart en alle parameters worden hersteld naar de standaard.

Installatie

Stap 1 Inschakelen

Sluit het netsnoer aan op de camera en op de voedingsadapter en vervolgens op een wandcontactdoos, zoals aangegeven in onderstaande afbeelding.



Stap 2 Installatie van de camera


1. Een gebruikersaccount aanmaken



- Verbind uw mobiele telefoon met de wifi.
- Download en installeer de EZVIZ-app door "EZVIZ" te zoeken in App Store of Google Play™.
- Start de app en registreer een EZVIZ-gebruikersaccount via de opstartwizard.


2. Een camera toevoegen aan EZVIZ

- Meld u aan in de EZVIZ-app.
- Tik vanuit het startscherm van de EZVIZ-app op "+" in de rechterbovenhoek om naar de interface QR-code te gaan.



- Scan de QR-code aan de onderkant van de camera.

Onderkant van de camera



- Volg de wizard van de EZVIZ-app om de wifi-configuratie te voltooien.

i Zorg dat uw telefoon is verbonden met de 2,4 GHz wifi van de router voor wifi-configuratie.

Installatie


Stap 1 Installeer de metalen plaat (optioneel)

Kies een schone en vlakke ondergrond en bevestig de metalen plaat op de gewenste positie met de schuimstickers of schroeven (niet meegeleverd).

- i** Er zit een magnetisch onderdeel in de camera. U kunt deze stap overslaan als het oppervlak van metaal is gemaakt.

Stap 2 Installeer de camera

Plaats de camera magnetisch op de metalen plaat of het metalen oppervlak (zie onderstaande afbeelding).




Stap 3 Voltooien van de installatie

Pas de camerahoek indien nodig aan.

Bijlage


Geheugenkaart installeren

Plaats een microSD kaart in de sleuf tot een hoorbare klik.



Geheugenkaart initialiseren

1. Controleer de geheugenkaartstatus in de EZVIZ-app door op **Storage Status (Opslagstatus)** in de interface **Device Settings (Apparaatinstellingen)** te tikken.



2. Als de status van de geheugenkaart niet als **Uninitialized (Niet geïnitieerd)** wordt weergegeven, tik er dan op om deze te initialiseren. De status verandert dan in **Normal (Normaal)**.



Bezoek voor meer informatie www.ezvizlife.com.