

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezvizlife.com>).

### **Revision Record**

New release – January, 2019

### **Trademarks Acknowledgement**

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Conteúdo da caixa



Câmara de internet  
(x1)



Cabo USB (x1)



Adaptador de  
alimentação (x1)



Autocolante de  
espuma (x2)



Placa metálica  
(x1) (orifício com  
diâmetro de 3,5  
mm)





Informações  
sobre as normas  
reguladoras (x1)



Guia de Início  
Rápido (x1)

**i** O aspeto da câmara depende do modelo adquirido.

# Apresentação




Nome	Descrição
Luz indicadora LED	<ul style="list-style-type: none"> <li>• Luz vermelha: A câmara está a iniciar.</li> <li>• Vermelho intermitente lento: Falha de ligação à rede Wi-Fi.</li> <li>• Vermelho intermitente rápido: Exceção de dispositivo (p. ex., erro no cartão microSD).</li> <li>• Azul sólido: O vídeo está a ser visualizado ou reproduzido na App EZVIZ.</li> <li>• Azul intermitente rápido: A câmara está pronta para a ligação à rede Wi-Fi.</li> <li>• Azul intermitente lento: A câmara está a funcionar corretamente.</li> </ul>
Cartão microSD	<p>O cartão microSD deve ser comprado em separado. Inicialize o cartão na aplicação EZVIZ antes de o utilizar.</p>
Botão de REINICIALIZAÇÃO	<p>Mantenha o botão de REINICIALIZAÇÃO premido durante 5 segundos enquanto a câmara estiver ligada; a câmara irá reiniciar e serão repostas as predefinições de todos os parâmetros.</p>

# Configuração

## Passo 1 Ligar

Ligue o cabo de alimentação à câmara e ao adaptador de energia e de seguida a uma tomada elétrica, conforme indicado na figura abaixo.



## Passo 2 Configuração da câmara


### 1. Crie uma conta de utilizador



- Ligue o telemóvel à rede Wi-Fi.
- Transfira e instale a aplicação EZVIZ pesquisando "EZVIZ" na App Store ou Google Play™.
- Inicie a App e registe-se para criar uma conta de utilizador EZVIZ seguindo o assistente de configuração.


### 2. Adicionar uma câmara ao EZVIZ

- Inicie sessão na App EZVIZ.
- A partir do ecrã inicial da App EZVIZ, toque no símbolo "+" no canto superior direito e siga para a interface da leitura do código QR.



- Leia o Código QR na parte inferior da câmara.

Parte inferior da câmara



- Siga o assistente da aplicação EZVIZ para completar a configuração Wi-Fi.

**i** Certifique-se de que o seu telefone se encontra ligado à rede Wi-Fi de 2,4 GHz a partir do router para configuração da rede Wi-Fi.

# Instalação


## Passo 1 Instale a Placa metálica (opcional)

Escolha uma superfície limpa e lisa e fixe a placa de metal na posição desejada com os autocolantes de espuma ou parafusos (não incluídos).

- i** Existe um ímã no interior da câmara. Pode ignorar este passo se a superfície for metálica.

## Passo 2 Instale a câmara

Fixe a câmara de forma magnética à placa de metal ou superfície metálica (ver figura abaixo).



## Passo 3 Conclua a instalação


Ajuste o ângulo da câmara conforme necessário.



# Anexo

## Instalar o cartão de memória

Insira um cartão microSD na ranhura até ouvir um "clique".



## Inicializar o cartão de memória

1. Na aplicação EZVIZ, verifique o estado do cartão de memória tocando no **"Storage Status" (Estado de armazenamento)** na interface **"Device Settings" (Definições do dispositivo)**.

Wi-Fi Configure	TEST-WiFi	📶	>
Storage Status			>
Device Version	Vx.x.x build xxxxxx		No new version.

2. Se o estado do cartão de memória estiver indicado como **"Uninitialized" (Não inicializado)**, toque para o inicializar. O estado irá, depois, mudar para **Normal**.



Para obter informações detalhadas, visite o website [www.ezvizlife.com](http://www.ezvizlife.com).