

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Thành phần trong hộp



Internet Camera (x1)



Cáp USB (x1)



Bộ chuyển đổi điện (x1)



Miếng dán xốp
(x2)



Tấm kim loại (x1)
(Đường kính lỗ
3,5mm)





Thông tin Quy
định (x1)



Hướng dẫn sử
dụng nhanh (x1)

i Hình dáng của camera tùy thuộc vào thực tế sản phẩm bạn đã mua.

Tính năng cơ bản



Tên

Mô tả

Đèn LED

- Sáng đỏ: Camera đang khởi động.
- Nháy chậm màu đỏ: Kết nối Wi-Fi không thành công.
- Nháy nhanh màu đỏ: Ngoại lệ thiết bị (ví dụ: lỗi thẻ nhớ microSD).
- Sáng xanh dương: Video đang được xem hoặc phát lại trên ứng dụng EZVIZ.
- Nháy nhanh màu xanh dương: Camera đã sẵn sàng để kết nối Wi-Fi.
- Nháy chậm màu xanh dương: Camera đang hoạt động bình thường.

Thẻ microSD

Nên mua thẻ microSD riêng.
Khởi tạo thẻ trong ứng dụng EZVIZ trước khi sử dụng.


Nút khởi động lại

Nhấn nút khởi động lại khoảng 5 giây trong khi camera đang chạy, camera sẽ khởi động lại và tắt cả các tham số được đặt về thông số mặc định.

Cài đặt

Bước 1 Cấp điện

Cắm cáp nguồn vào máy ảnh và vào bộ chuyển đổi điện và sau đó vào ổ cắm điện, như trong hình dưới đây.



Bước 2 Cài đặt camera


1. Tạo tài khoản người dùng




- Kết nối điện thoại di động của bạn vào mạng Wi-Fi.
- Tải về và cài đặt ứng dụng EZVIZ bằng cách tìm kiếm "EZVIZ" trong App Store và Google Play™.
- Bật ứng dụng và đăng ký tài khoản trên ứng dụng Ezviz và làm theo hướng dẫn trên ứng dụng.

2. Thêm camera vào EZVIZ.

- Đăng nhập vào ứng dụng EZVIZ.
- Từ màn hình Trang chủ của ứng dụng EZVIZ, nhấn vào biểu tượng "+" ở góc trên cùng bên phải để chuyển đến giao diện quét mã QR.



- Quét mã QR ở dưới chân camera.



- Thực hiện theo trình hướng dẫn của ứng dụng EZVIZ để hoàn tất việc định cấu hình Wi-Fi.

i Hãy đảm bảo rằng điện thoại của bạn được kết nối với Wi-Fi 2,4 GHz từ bộ định tuyến để cấu hình Wi-Fi.

Lắp đặt


Step 1 Lắp đặt Tấm kim loại (Tùy chọn)

Chọn một bề mặt sạch và phẳng và cố định tấm kim loại vào vị trí mong muốn bằng miếng dán bọt biển hoặc ốc vít (không bao gồm trong bộ sản phẩm).

- i** Bên trong camera có thanh nam châm. Bạn có thể bỏ qua bước này nếu bề mặt lắp đặt làm bằng kim loại.

Step 2 Lắp đặt Camera

Cố định chặt camera vào tấm kim loại hoặc bề mặt kim loại nhờ từ lực của nam châm (xem hình bên dưới).




Step 3 Hoàn thành lắp đặt

Điều chỉnh góc camera như yêu cầu.

Phụ lục


Lắp đặt thẻ nhớ

Lắp thẻ MicroSD vào khe cho đến khi nghe thấy tiếng tách.



Đang khởi tạo thẻ nhớ

1. Trong ứng dụng EZVIZ, hãy kiểm tra trạng thái thẻ nhớ bằng cách chạm vào Storage Status (Trạng thái Bộ nhớ) trong giao diện Device Settings (Cài đặt Thiết bị).

Wi-Fi Configure	TEST-WiFi  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. Nếu thẻ nhớ hiển thị ở trạng thái Uninitialized (Chưa được khởi tạo), bấm vào để khởi tạo. Trạng thái sau đó sẽ thay đổi sang Normal (Bình thường).



Để biết thông tin chi tiết, vui lòng truy cập www.ezvizlife.com.