COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ " website (http://www.ezvizlife.com).

Revision Record

New release - January, 2019

Trademarks Acknowledgement

EZVIZ [™], Joan and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL. CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS. BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT. EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY

OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS, REGARDING TO THE PRODUCT WITH INTERNET ACCESS.

THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS: HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION, PLEASE

CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILL EGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE


APPLICABLE LAW. THE LATTER PREVAILS.

同梱物



カメラの外観は、ご購入いただいた実際のモデルと異なる場合があります。

基本操作



名前 説明

LED インジ・赤で点灯:カメラが起動中です。

ケータ ・ ゆっくり赤で点滅:Wi-Fi 接続が失敗しました。

速く赤で点滅:デバイスに異常 (例:MicroSD カードのエラー)が発生しています。

・ 青で点灯:EZVIZ アプリでビデオの表示もしくは再生中

です。
・ 速く青で点滅:カメラは Wi-Fi 接続可能状態です。

・ 述べ自じ 宗滅・カメラは WiFi 按続可能依然です。・ ゆっくり 書で点滅:カメラは 正常に動作しています。

・ ゆつくり育で点滅・カメラは正常に割作していまり microSD カードは別涂購入する必要があります。

カード リセットボ タン


使用前に EZVIZ アプリで初期化してください。 カメラの動作中にリセット ボタンを 5 秒間長押しすると、 カメラが再起動し、すべてのパラメータがデフォルトにリ

セットされます。

セットアップ

ステップ 1 電源オン

下図のように、電源ケーブルをカメラと電源アダプターに接続し、 電源アダプターを電源コンセントに接続してください。




ステップ 2 カメラのセットアップ

1.ユーザアカウントを作成する

- スマートフォンを Wi-Fi に接続します。
- App Store または Google Play[™] で「EZVIZ」で検索し、EZVIZ アプリをダウンロードしてインストールします。
- アプリを起動し、スタートアップウィザードにしたがって EZVIZ ユーザアカウントを登録してください。

2. EZVIZ にカメラを追加する

- EZVIZ アプリにログインします。
- EZVIZ アプリのホーム画面で右上隅の「+」をタップし、QR コードスキャンインターフェイスを開きます。



- カメラ底面の QR コードをスキャンします。



- EZVIZ アプリのウィザードにしたがって、Wi-Fi 設定を完了します。
- Wi-Fi 設定時は、お使いのスマートフォンがルータからの 2.4GHz Wi-Fi に接続されていることを確認してください。

設置


ステップ 1 メタルプレートの設置 (オプション)

清潔で平らな壁面を選択し、フォームステッカーまたはネジ (同梱されていません)で希望の位置に固定します。

カメラには磁石が内蔵されています。金属面の場合にはこの 手順をスキップすることができます。

ステップ 2 カメラの設置

磁力でカメラをメタルプレートまたは金属面に固定します (下図を参照)。



ステップ 3 設置完了 必要に合わせてカメラの角度を調整します。

付録

メモリカードの取り付け

microSD カードをスロットに、カチッと音がするまで押し込みます。



メモリカードの初期化

1. EZVIZ アブリで、Device Settings (デバイス設定) インターフェイスの Storage Status (ストレージステータス) をタップし、メモリカードのス テータスをチェックします。



- メモリカードのステータスが「Uninitialized」(未初期化)と表示されている場合、タップして初期化します。すると、ステータスがNormal(正常)に変化します。
 - i 詳細情報については www.ezvizlife.com を参照してください。