

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

 and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Kassens indhold



Internetkamera (x1)



USB-kabel (x1)



Strømadapter (x1)



Skumsticker
(x2)



Metalplade (x1)
(hul med diameter
på 3,5 mm)



Lovgivnings-
mæssige
oplysninger
(x1)





Startvejledning
(x1)



Udseendet på det købte kamera kan afvige fra vejledningen.

Grundlæggende oplysninger




Navn	Beskrivelse
LED-kontrolllampe	<ul style="list-style-type: none">• Lyser konstant rødt: Kameraet starter op.• Blinker langsomt rødt: Wi-fi-forbindelsen er afbrudt.• Blinker hurtigt rødt: Undtagelse på enhed (fx fejl i microSD-kort).• Lyser konstant blå: En video vises eller afspilles i appen EZVIZ.• Blinker hurtigt blå: Kameraet er klar til wi-fi-forbindelsen.• Blinker langsomt blå: Kameraet fungerer korrekt.
microSD-kort	microSD-kort skal købes særskilt. Formatér kortet med EZVIZ-appen før brug.
NULSTIL-knap	Hold knappen NULSTIL nede i 5 sekunder, mens kameraet er tændt. Kameraet genstarter, og alle indstillinger nulstilles til standard.

Installation

Trin 1 Tænd for strømmen

Sæt strømledningen i kameraet og i strømadapteren og derefter i en stikkontakt som vist i figuren nedenfor.



Trin 2 Konfiguration af kamera


1. Opret en brugerkonto



- Slut din mobiltelefon til wi-fi-netværket.
- Hent og installér appen EZVIZ ved at søge efter "EZVIZ" i App Store eller Google Play™.
- Start appen, og registrér en EZVIZ-brugerkonto ved at følge opstartsguiden.


2. Tilføj et kamera til EZVIZ

- Log ind på appen EZVIZ.
- Tryk på "+" i øverste højre hjørne af startskærmen i appen EZVIZ for at gå til siden til scanning af QR-koden.



- Scan QR-koden på bunden af kameraet.

Bunden på kameraet



- Følg vejledningen i EZVIZ-appen for at færdiggøre konfiguration af wi-fi.

- i Kontrollér, at telefonen er sluttet til wi-fi-netværket på 2,4 GHz fra routeren med henblik på wi-fi-konfiguration.

Installation


Trin 1 Installation af metalplade (valgfrit)

Vælg en ren og flad overflade, og fastgør metalpladen til den ønskede position med skumstickers eller skruer (medfølger ikke).

- i** Der er en magnet i kameraet. Du kan springe trinet over, hvis overfladen er af metal.

Trin 2 Installation af kamera

Fastgør kameraet magnetisk til metalpladen eller metaloverfladen (se figuren nedenfor).




Trin 3 Afslutning af installation

Justér kameravinklen efter behov.

Bilag

Installation af hukommelseskort

Sæt et microSD-kort i holderen, indtil det klikker.



Initialisering af hukommelseskort

1. Kontrollér hukommelseskortets status i appen EZVIZ ved at trykke på **Storage Status (Lagerstatus)** på skærmen **Device Settings (Enhedsindstillinger)**.

Wi-Fi Configure	TEST-WiFi	WiFi icon	>
Storage Status			>
Device Version	Vx.x.x build xxxxxx No new version.		

2. Hvis hukommelseskortets status vises som **Uninitialized (Ikke initialiseret)**, skal du trykke for at initialisere kortet. Status ændres til **Normal**.



Besøg www.ezvizlife.com for flere oplysninger.