

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Contenido de la caja



1 Cámara de Internet



1 Cable USB



1 Adaptador de corriente



2 Adhesivos de espuma



1 Placa metálica
(diámetro del orificio de 3,5 mm)





1 información normativa



1 Guía de inicio rápido

i La apariencia de la cámara está sujeta a la cámara real que haya comprado.

Elementos básicos




Nombre	Descripción
Indicador LED	<ul style="list-style-type: none"> • Rojo fijo: la cámara se está iniciando. • Rojo parpadeando lentamente: fallo en la conexión wifi. • Rojo parpadeando rápidamente: Problemas con el dispositivo (p.ej. error de la tarjeta microSD). • Azul fijo: el vídeo se está viendo o reproduciendo en la aplicación EZVIZ. • Azul parpadeando rápidamente: la cámara está preparada para conectarse a la red wifi. • Azul parpadeando lentamente: la cámara está funcionando correctamente.
Tarjeta microSD	<p>La tarjeta microSD se debe comprar por separado. Inicialice la tarjeta en la aplicación EZVIZ antes de usarla.</p>
Botón REINICIO	<p>Mantenga pulsado el botón de REINICIO durante 5 segundos con la cámara en funcionamiento. La cámara se reiniciará y recuperará los parámetros predeterminados de fábrica.</p>

Instalación

Paso 1 Encendido

Conecte el cable de alimentación a la cámara y al adaptador de corriente y después a una toma. Consulte la siguiente figura.



Paso 2 Configuración de la cámara


1. Cree una cuenta de usuario




- Conecte su teléfono móvil a la red Wi-Fi.
- En la App Store o en Google Play™, busque «EZVIZ» para descargar e instalar la aplicación.
- Abra la aplicación y registre una cuenta de usuario EZVIZ siguiendo las instrucciones del asistente de instalación.

2. Agregue una cámara a EZVIZ

- Inicie sesión en la aplicación EZVIZ.
- Desde la pantalla de inicio de la app EZVIZ, toque el símbolo "+" situado en la esquina superior derecha para entrar en la interfaz de escaneo del código QR.



- Escanee el código QR que figura en la parte inferior de la cámara.



- Siga las indicaciones del asistente de la aplicación EZVIZ para finalizar la configuración del Wi-Fi.

i Para la configuración de la red wifi, asegúrese de que su móvil esté conectado a la red de 2,4 GHz del enrutador.

Instalación


Paso 1 Instale la placa metálica (opcional)

Seleccione una superficie lisa y limpia y coloque la placa de metal en la posición deseada con los adhesivos de espuma o tornillos (no incluidos).

- i** En el interior de la cámara hay un imán. Si la superficie de instalación es metálica, puede omitir este paso.

Paso 2 Instale la cámara

Monte la cámara en la placa de metal o superficie metálica usando el imán (consulte la siguiente figura).




Paso 3 Fin de la instalación

Ajuste el ángulo de la cámara según sea necesario.

Apéndice


Instalar la tarjeta de memoria

Inserte la tarjeta microSD en la ranura hasta encajarla.



Inicialización de la tarjeta de memoria

1. En la aplicación EZVIZ, compruebe el estado de la tarjeta de memoria tocando sobre la opción **Storage Status (Estado de almacenamiento)** en la interfaz **Device Settings (Ajustes del dispositivo)**.



2. Si el estado de la tarjeta de memoria aparece como **Uninitialized (No inicializado)**, tóquelo para inicializarla. Entonces el estado cambiará a **Normal**.



Para obtener información detallada, visite www.ezvizlife.com.