

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

### **Revision Record**

New release – January, 2019

### **Trademarks Acknowledgement**

**EZVIZ™**, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Isi Kotak



Kamera Internet (x1)



Kabel USB (x1)



Adaptor Daya (x1)



Stiker Busa (x2)



Pelat Logam (x1)  
(Diameter Lubang  
3,5 mm)





Informasi  
Peraturan (x1)



Panduan Mulai  
Cepat (x1)

**i** Tampilan kamera dapat berbeda sesuai dengan kamera yang Anda beli.

# Dasar-dasar




## **Nama**            **Deskripsi**

Indikator LED	<ul style="list-style-type: none"><li>• Merah Pekat: Kamera sedang memulai.</li><li>• Merah Berkedip Pelan: Sambungan Wi-Fi gagal.</li><li>• Merah Berkedip Cepat: Pengecualian perangkat (misalnya, kesalahan kartu microSD).</li><li>• Biru Pekat: Video sedang ditampilkan atau diputar di Aplikasi EZVIZ.</li><li>• Biru Berkedip Cepat: Kamera siap untuk sambungan Wi-Fi.</li><li>• Biru Berkedip Pelan: Kamera berfungsi dengan baik.</li></ul>
Kartu microSD	Kartu microSD Card dijual terpisah. Inisialisasi kartu dalam aplikasi EZVIZ sebelum menggunakannya.
Tombol RESET	Tahan tombol RESET selama 5 detik saat kamera sedang berjalan, lalu kamera memulai ulang dan semua parameter diatur ulang ke pengaturan awal.


# Pengaturan


## Langkah 1 Nyalakan daya

Colokkan kabel daya ke kamera dan ke adaptor daya lalu ke stopkontak daya, seperti ditunjukkan pada gambar di bawah.




## Langkah 2 Pengaturan Kamera

1. Buat akun pengguna 
  - Sambungkan telepon seluler Anda ke Wi-Fi.
  - Unduh dan pasang aplikasi EZVIZ dengan mencari "EZVIZ" di App Store dan Google Play™.
  - Buka aplikasi dan lakukan pendaftaran akun pengguna EZVIZ dilanjutkan dengan petunjuk memulai.
2. Tambahkan kamera ke EZVIZ
  - Masuk ke aplikasi EZVIZ.
  - Dari layar Utama aplikasi EZVIZ, ketuk tanda "+" di sudut kanan atas untuk membuka antarmuka pemindaian kode QR.



- Pindai kode QR pada bagian bawah kamera.



- Ikuti wizard aplikasi EZVIZ untuk menyelesaikan konfigurasi Wi-Fi.

**i** Pastikan ponsel Anda tersambung ke Wi-Fi 2.4GHz dari router untuk konfigurasi Wi-Fi.

# Pemasangan


## Langkah 1 Pasang Pelat Logam (Opsional)

Gunakan permukaan yang bersih dan datar serta lekatkan pelat logam dengan stiker busa atau sekrup ke posisi yang diinginkan (tidak disertakan).

- i** Terdapat potongan magnet di dalam kamera. Anda dapat melewati langkah ini jika permukaan terbuat dari logam.

## Langkah 2 Pasang Kamera

Kencangkan kamera secara magnetis ke pelat logam atau permukaan logam (lihat gambar di bawah).



## Langkah 3 Menyelesaikan Pemasangan


Sesuaikan sudut kamera jika diperlukan.



# Lampiran


## Pasang Kartu Memori

Masukkan kartu MicroSD ke dalam slot hingga terdengar bunyi "klik".



## Menginisialisasi Kartu Memori

1. Di aplikasi EZVIZ, periksa status kartu memori dengan mengetuk **Storage Status (Status Penyimpanan)** di antarmuka **Device Settings (Pengaturan Perangkat)**.

Wi-Fi Configure	TEST-WIFI  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. Jika status kartu memori ditampilkan sebagai **Uninitialized (Belum Terinisialisasi)**, ketuk untuk menginisialisasikannya. Status kemudian akan berubah menjadi **Normal**.

 Untuk informasi selengkapnya, kunjungi [www.ezvizlife.com](http://www.ezvizlife.com).