

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

### **Revision Record**

New release – January, 2019

### **Trademarks Acknowledgement**

**EZVIZ™**, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Zawartość opakowania



Kamera internetowa (x1)



Przewód USB (x1)



Zasilacz (x1)



Taśma  
montażowa  
dwustronna  
(x2)



Płytkę metalową (x1)  
(średnica otworu  
3,5 mm)




Informacje  
dotyczące  
przepisów (x1)



Skrócona  
instrukcja  
obsługi (x1)

**i** Wygląd kamery jest zależny od modelu.

# Podstawowe informacje




Nazwa	Opis
Wskaźnik LED	<ul style="list-style-type: none"> <li>• Włączony (czerwony): kamera jest uruchamiana.</li> <li>• Miga powoli (czerwony): połączenie z siecią Wi-Fi nie powiodło się.</li> <li>• Miga szybko (czerwony): błąd urządzenia (np. błąd karty microSD).</li> <li>• Włączony (niebieski): przeglądanie lub odtwarzanie nagrań wideo w aplikacji EZVIZ.</li> <li>• Miga szybko (niebieski): kamera jest gotowa do połączenia z siecią Wi-Fi.</li> <li>• Miga powoli (niebieski): kamera działa prawidłowo.</li> </ul>
Karta microSD	<p>Kartę microSD należy zakupić oddzielnie. Przed użyciem karty należy ją zainicjować w aplikacji EZVIZ.</p>
Przycisk resetowania	<p>Naciśnij i przytrzymaj przycisk RESETUJ przez 5 sekund, gdy kamera jest uruchomiona. Kamera zostanie ponownie uruchomiona i zostaną przywrócone wartości domyślne wszystkich parametrów.</p>

# Konfiguracja

## Krok 1 Włączanie

Podłącz przewód zasilający do kamery, zasilacza i gniazda sieci elektrycznej, jak przedstawiono na poniższym rysunku.



## Krok 2 Konfiguracja kamery


### 1. Stwórz konto użytkownika




- Połącz telefon komórkowy z siecią Wi-Fi.
- Pobierz i zainstaluj aplikację EZVIZ, wyszukując „EZVIZ” w witrynie App Store lub Google Play™.
- Uruchom aplikację i zarejestruj swoje konto użytkownika EZVIZ przy użyciu kreatora startowego.

### 2. Dodaj kamerę do aplikacji EZVIZ

- Zaloguj się w aplikacji EZVIZ.
- Na ekranie głównym aplikacji EZVIZ naciśnij przycisk „+” znajdujący się w prawym górnym rogu, aby przejść do interfejsu skanowania kodu QR.



- Zeskanuj kod QR znajdujący się na spodzie kamery.



- Postępuj zgodnie z instrukcjami wyświetlanymi w kreatorze aplikacji EZVIZ, aby ukończyć konfigurację Wi-Fi.

**i** Aby skonfigurować sieć Wi-Fi, upewnij się, że Twój telefon jest połączony z siecią Wi-Fi 2,4 GHz routera.

# Instalacja


## Krok 1 Instalacja płytki metalowej (opcjonalnie)

Wybierz czystą i płaską powierzchnię, a następnie przymocuj płytkę metalową w wybranej pozycji, korzystając w tym celu z pianki przylepnej lub śrub (nie wchodzą w skład zestawu).

- i** Wewnątrz kamery znajduje się magnes. Jeżeli powierzchnia montażowa jest wykonana z metalu, można pominąć ten krok.

## Krok 2 Instalacja kamery

Przymocuj kamerę za pomocą magnesu do przykręconej płytki metalowej lub metalowej powierzchni montażowej (patrz rysunek poniżej).



## Krok 3 Zakończenie instalacji


Dostosuj kąt widzenia kamery zgodnie z wymaganiami.



# Dodatek


## Włóż kartę pamięci

Wsuń kartę microSD do gniazda, tak aby została zablokowana w odpowiednim położeniu.



## Inicjowanie karty pamięci

1. Sprawdź stan karty pamięci, wybierając w tym celu opcję **Storage Status (Stan pamięci)** w interfejsie **Device Settings (Ustawienia urządzenia)** w aplikacji EZVIZ.



2. Jeżeli wyświetlany jest stan karty pamięci **Uninitialized (Niezainicjowana)**, naciśnij przycisk, aby ją zainicjować. Stan zostanie zmieniony na **Normal (Normalny)**.



Aby uzyskać więcej informacji, skorzystaj z witryny [www.ezvizlife.com](http://www.ezvizlife.com).