

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Conteúdo da embalagem



Webcam (1 unidade)



Cabo USB (1 unidade)



Adaptador de corrente
(1 unidade)



Adesivo de
espuma
(2 unidades)



Placa de metal
(1 unidade)
(diâmetro do
furo: 3,5 mm)




Informações
regulamentares
(1 unidade)



Guia de Início
Rápido
(1 unidade)

i A aparência da câmera está sujeita à que você comprou.

Elementos básicos




Nome	Descrição
Indicador de LED	<ul style="list-style-type: none"> • Vermelho fixo: a câmera está iniciando. • Vermelho piscando lentamente: a conexão Wi-Fi falhou. • Vermelho piscando rapidamente: exceção do dispositivo (por exemplo, erro do cartão MicroSD). • Azul fixo: o vídeo está sendo visualizado ou reproduzido no aplicativo EZVIZ. • Azul piscando rapidamente: a câmera está pronta para a conexão Wi-Fi. • Azul piscando lentamente: a câmera está funcionando adequadamente.
Cartão microSD	<ul style="list-style-type: none"> • O cartão microSD deve ser adquirido separadamente. • Inicialize o cartão no aplicativo EZVIZ antes de usá-lo.
Botão REDEFINIR	<p>Mantenha o botão REDEFINIR pressionado por 5 segundos enquanto a câmera estiver em funcionamento. A câmera reiniciará e todos os parâmetros serão redefinidos para o modo padrão.</p>

Configuração

Passo 1 Conexão

Conecte o cabo de alimentação à câmera e ao adaptador de corrente. Em seguida, conecte-o à tomada elétrica, como mostrado na figura abaixo.



Passo 2 Configuração da câmera


1. Criar uma conta de usuário




- Conecte seu celular à rede Wi-Fi.
- Baixe e instale o aplicativo EZVIZ pesquisando "EZVIZ" na Apple Store ou Google Play™.
- Abra o aplicativo e registre uma conta de usuário do EZVIZ seguindo as instruções do assistente de inicialização.

2. Adicionar uma câmera ao EZVIZ

- Efetue o login no aplicativo EZVIZ.
- Na tela inicial do aplicativo, toque em "+" no canto superior direito para acessar a interface de leitura de códigos QR.



- Faça a leitura do código QR localizado na base da câmera.



- Siga as instruções do assistente do aplicativo EZVIZ para concluir a configuração do Wi-Fi.

i Verifique se o telefone está conectado ao Wi-Fi de 2.4 GHz do roteador para configuração de Wi-Fi.

Instalação


Passo 1 Instale a placa de metal (opcional)

Escolha uma superfície limpa e plana e prenda a placa de metal na posição desejada com os adesivos de espuma ou com parafusos (não incluídos).

- i** Há uma placa com ímã dentro da câmera. Você pode pular esta etapa se a superfície for feita de metal.

Passo 2 Instale a câmera

Prenda a câmera magnética na placa ou superfície de metal (veja a figura abaixo).




Passo 3 Complete a instalação

Ajuste o ângulo da câmera, conforme necessário.

Apêndice

Instalar o cartão de memória

Insira o cartão microSD na ranhura até ouvir um clique.



Inicializando o cartão de memória

1. No aplicativo EZVIZ, verifique o status do cartão de memória tocando em **Storage Status (Status do armazenamento)** na interface **Device Settings (Configurações do dispositivo)**.

Wi-Fi Configure	TEST-WiFi	📶	>
Storage Status			>
Device Version	Vx.x.x build xxxxxx		No new version.

2. Se o status do cartão de memória for exibido como **Unitialized (Não inicializado)**, toque para inicializá-lo. O status será alterado para **Normal**.



Para obter informações detalhadas, visite www.ezvizlife.com.