

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

### **Revision Record**

New release – January, 2019

### **Trademarks Acknowledgement**

**EZVIZ™**, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Obsah balenia



Internetová kamera (1x)



Kábel USB (1x)



Sieťový adaptér (1x)



Penová nálepka (2x)



Kovová platňa(1x)  
(priemer otvoru  
3,5 mm)





Regulačné informácie (1x)



Príručka so stručným návodom (1x)

**i** Vzhľad kamery závisí od zakúpeného modelu.

# Základné informácie




Názov	Popis
Indikátor LED	<ul style="list-style-type: none"> <li>• Neprerušovaná červená: Kamera sa spúšťa.</li> <li>• Pomalé blikanie načerveno: Zlyhalo pripojenie k sieti Wi-Fi.</li> <li>• Rýchle blikanie načerveno: Výnimka zariadenia (napr. chyba karty microSD).</li> <li>• Neprerušovaná modrá: Video sa zobrazuje alebo prehráva v aplikácii EZVIZ.</li> <li>• Rýchle blikanie namodro: Kamera je pripravená na pripojenie k sieti Wi-Fi.</li> <li>• Pomalé blikanie namodro: Kamera funguje správne.</li> </ul>
Karta microSD	Karta microSD by sa mala zakúpiť samostatne. Pred použitím kartu inicializujte v aplikácii EZVIZ.
Tlačidlo RESET	Keď je kamera spustená, podržte stlačené tlačidlo RESET na 5 sekúnd a všetky parametre sa resetujú na predvolené.

# Nastavenie

## Krok 1 Zapnutie

Pripojte napájací kábel ku kamere a k napájaciemu adaptéru a potom do zásuvky napájania podľa zobrazenia na obrázku nižšie.



## Krok 2 Nastavenie kamery


### 1. Vytvorenie používateľského účtu



- Pripojte mobilný telefón k sieti Wi-Fi.
- Stiahnite si a nainštalujte aplikáciu EZVIZ vyhľadáním slova „EZVIZ“ na lokalite App Store alebo Google Play™.
- Spustíte aplikáciu a zaregistrujte používateľský účet EZVIZ podľa sprievodcu pri spustení.


### 2. Pridanie kamery do účtu EZVIZ

- Prihláste sa do aplikácie EZVIZ.
- Na obrazovke Home (Domov) aplikácie EZVIZ klepnite na znamienko „+“ v pravom hornom rohu, aby ste prešli do rozhrania skenovania QR kódu.



- Naskenujte QR kód v spodnej časti kamery.

Spodná časť kamery



- Postupujte podľa sprievodcu aplikácie EZVIZ a dokončite konfiguráciu siete Wi-Fi.

**i** Uistite sa, že váš telefón je pripojený k 2,4 GHz sieti Wi-Fi zo smerovača na konfiguráciu siete Wi-Fi.

# Inštalácia


## Krok 1 Nainštalujte kovovú platňu (voliteľné)

Vyberte čistý a rovný povrch a upevnite kovovú platňu do požadovanej polohy pomocou penových nálepiek alebo skrutiek (nie sú súčasťou balenia).

- i** Vnútri kamery sa nachádza magnetická súčasť. Tento krok môžete preskočiť, ak je povrch z kovu.

## Step 2 Nainštalujte kameru

Magneticky zaistíte kameru na kovovú platňu alebo kovový povrch (pozri obrázok nižšie).



## Krok 3 Dokončenie inštalácie


Podľa potreby nastavte uhol kamery.



# Dodatok


## Vloženie pamäťovej karty

Vložte kartu MicroSD do slotu, kým neklikne.



## Inicializácia pamäťovej karty

1. V aplikácii EZVIZ skontrolujte stav pamäťovej karty klepnutím na položku **Storage Status (Stav úložiska)** v rozhraní **Device Settings (Nastavenia zariadenia)**.



2. Ak sa stav pamäťovej karty zobrazuje ako **Uninitialized (Neinicializovaný)**, klepnite naň, aby sa inicializoval. Stav sa následne zmení na **Normal (Normálny)**.



Podrobné informácie nájdete na stránke [www.ezvizlife.com](http://www.ezvizlife.com).