

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ’s trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS,

EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Pakkauksen sisältö



Internet-kamera (x1)



USB-kaapeli (x1)



Verkkolaite (x1)



Tarratyyny (x2)



Metallilevy (x1)
(3,5 mm:n reiän halkaisija)





Tietoja
säädöksistä (x1)



Pika-
aloitusopas
(x1)

i Kameran todellinen ulkonäkö riippuu ostamastasi tuotteesta.

Perustiedot



Nimi

Kuvaus

LED-
merkkivalo

- Tasaisesti palava punainen: kamera käynnistyy.
- Hitaasti vilkkuva punainen: Wi-Fi-yhteys on katkennut.
- Nopeasti vilkkuva punainen: Laitevika (esim. microSD-kortin virhe).
- Tasaisesti palava sininen: videota katsotaan tai toistetaan EZVIZ-sovelluksessa.
- Nopeasti vilkkuva sininen: kamera on valmis Wi-Fi-yhteyden muodostukseen.
- Hitaasti vilkkuva sininen: kamera toimii oikein.

Micro SD
-kortti

microSD-kortti on ostettava erikseen.
Alusta kortti EZVIZ-sovelluksessa ennen käyttöä.


NOLLAUS-
painike

Pidä NOLLAUS-painiketta painettuna 5 sekuntia, kun kamera on käynnissä, jolloin kamera käynnistyy uudelleen ja kaikki asetukset palautetaan oletusasetuksiksi.

Määritys

1. vaihe Virta päälle

Kytke virtajohto kameraan ja verkkolaitteeseen ja sitten pistorasiaan alla olevassa kuvassa esitetyllä tavalla.




2. vaihe Kameran määritys

1. Luo käyttäjätili

- Yhdistä matkapuhelimesi Wi-Fi-verkkoon.
- Lataa ja asenna EZVIZ-sovellus hakusanalla "EZVIZ" App Storesta tai Google Play™-kaupasta.
- Käynnistä sovellus ja rekisteröi EZVIZ-käyttäjätili ohjatun käyttöönoton ohjeita noudattamalla.


2. Lisää kamera EZVIZ-tiliin

- Kirjaudu EZVIZ-sovellukseen.
- Siirry QR-koodin skannaussivulle napauttamalla EZVIZ-sovelluksen aloitusnäytön oikeassa yläkulmassa olevaa "+"-symbolia.



- Skannaaja kameran pohjassa oleva QR-koodi.

Kameran pohja



- Tee Wi-Fi-määritys loppuun käyttämällä EZVIZ-sovelluksen ohjattua toimintoa.

i Varmista, että puhelimesi on yhdistetty reitittimen 2,4 GHz:n Wi-Fi-yhteyteen Wi-Fi-määritystä varten.

Asennus


1. vaihe Metallilevyn asennus (valinnainen)

Kiinnitä metallilevy puhtaaseen ja tasaiseen kohtaan haluttuun asentoon tarratyynyillä tai ruuveilla (ei sisälly toimitukseen).

i Kameran sisällä on magneetti. Voit ohittaa tämän vaiheen, jos pinta on metallia.

2. vaihe Kameran asennus

Kiinnitä kamera metallilevyyn tai metallipintaan magneettisesti (katso alla oleva kuva).




3. vaihe Asennuksen viimeistely

Säädä kamera haluttuun kulmaan.

Liite


Muistikortin asentaminen

Aseta microSD-kortti korttipaikkaan niin, että se napsahtaa paikalleen.



Muistikortin alustaminen

1. Tarkista EZVIZ-sovelluksessa muistikortin tila valitsemalla **Storage Status (tallennustilan tila)** -valinta **Device Settings (laiteasetukset)** -näytössä.

Wi-Fi Configure	TEST-WiFi  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. Jos muistikortin tilana näkyy **Uninitialized (alustamaton)**, alusta se napauttamalla. Tilaksi tulee tämän jälkeen **Normal (normaali)**.

 Katso lisätietoa osoitteesta www.ezvizlife.com.