

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED. Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.


EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS. REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

설정

1 단계 전원 켜기

아래 그림과 같이 전원 케이블을 카메라와 전원 어댑터에 연결한 후 전원 콘센트에 꽂습니다.




2 단계 카메라 설정

1. 사용자 계정 생성


- 2.4GHz 네트워크를 사용해 모바일 폰을 Wi-Fi에 연결합니다.
- App Store 또는 Google Play™에서 "EZVIZ"를 검색하여 EZVIZ 앱을 다운로드한 다음 설치합니다.
- 앱을 실행하여 다음의 시작 마법사에 따라 EZVIZ 사용자 계정을 등록합니다.

2. EZVIZ에 카메라를 추가합니다.

- EZVIZ 앱에 로그인합니다.
- EZVIZ 앱 홈 화면의 오른쪽 구석 상단에 있는 "+"를 눌러 QR 코드 스캔 인터페이스로 이동하십시오.



- 카메라 바닥에 있는 QR 코드를 스캔합니다.




- EZVIZ 앱 마법사를 따라 Wi-Fi 구성을 완료하십시오.

i Wi-Fi 를 구성하기 위해 휴대전화가 라우터의 2.4GHz Wi-Fi 에 연결되어 있는지 확인해 주십시오.

3. 기본 비밀번호 변경 (선택 사항)

카메라를 추가한 후 비디오 보안을 위해 장비 비밀번호를 변경해야 합니다. 해당 비밀번호는 이미지를 암호화할 때 사용합니다. 이미지 암호화를 사용하도록 설정하면 실시간 보기를 실행하거나 카메라를 재생할 때 비밀번호를 입력해야 합니다.

- 카메라 설정 화면으로 이동해 기본 비밀번호를 변경하십시오.
- “Change Password(비밀번호 변경)”을 탭합니다.



- “Edit(편집)”을 탭합니다.
- 카메라 하단에 부착된 기본 인증 코드를 입력합니다.
- 신규 비밀번호를 입력합니다. 6~12 자의 문자와 숫자를 사용하십시오.

i 이 기기는 가정용으로 전자파적합등록을 한 기기로서 주거지역은 물론 모든 지역에서 사용할 수 있습니다. 위와 같은 무선설비는 전파혼선의 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다.

설치


1 단계 금속판 설치 (선택 사항)

깨끗하고 평평한 표면을 선택한 다음 발포 스티커 또는 나사 (미포함) 를 사용해 금속판을 원하는 위치에 고정합니다.

- i** 카메라에 자석이 내장되어 있습니다. 표면이 금속성일 경우 이 단계를 생략할 수 있습니다.

2 단계 카메라 설치


카메라를 금속판 또는 금속 표면에 자기로 고정합니다 (아래 그림 참조).



3 단계 설치 마무리

필요에 따라 카메라 각도를 조정합니다.

부록 기본 사항



명칭

설명

스피커	양방향 대화에 사용.
전원 입력	$\pm 5V \pm 10\%$
micro SD 카드	microSD 카드용 (이 제품에 포함되지 않음). 카드는 별도로 구매할 수 있습니다. 권장되는 호환성: 클래스 10, 최대 공간 256GB. 카드를 삽입한 다음 카메라 내부에 이벤트를 녹화할 수 있습니다.
초기화 버튼	카메라가 작동 중일 때 초기화 버튼을 5 초 동안 누릅니다. 그러면 카메라가 다시 시작되고 모든 매개변수가 기본값으로 초기화됩니다.

명칭

LED 표시등

설명

- 빨간색 켜짐 : 카메라가 시작 중입니다.
- 빨간색으로 느리게 깜박임 : Wi-Fi 연결에 실패했습니다.
- 빨간색으로 빠르게 깜박임 : 장비 비정상 (예 : MicroSD 카드 오류).
- 파란색 켜짐 : EZVIZ 앱에서 비디오를 보고 있거나 재생 중입니다.
- 파란색으로 빠르게 깜박임 : 카메라에 Wi-Fi 를 연결할 준비가 되었습니다.
- 파란색으로 천천히 깜박임 : 카메라가 올바르게 작동 중입니다.

IR 조명

어두운 환경을 위한 자동 광원. 이 비디오 카메라는 두 가지 모드가 있습니다. 하나는 컬러 모드 (주간 녹화용) 이며 다른 하나는 적외선 투광기를 사용하는 흑백 모드 (야간용) 입니다.

박스 내용물



카메라개 0



USB 케이블개



전원 어댑터개



발포 스티커개




금속판개
(구멍 직경 3.5mm)



빠른 시작 가이드 권


메모리 카드 설치

딸깍 소리가 날 때까지 microSD 카드를 슬롯에 삽입하십시오.



메모리 카드 초기화

1. EZVIZ 앱에서 Device Settings(장비 설정) 인터페이스의 Storage Status(저장소 상태) 를 탭하여 메모리 카드 상태를 확인합니다 .

Wi-Fi Configure	TEST-WIFI  >
Storage Status	>
Device Version	Vx.x.x build xxxxxx No new version.

2. 메모리 카드 상태가 Uninitialized(초기화되지 않음) 로 표시되면 탭하여 초기화합니다 . 그러면 상태가 Normal(정상) 으로 변경됩니다 . 이제 카메라에 동작 탐지와 같이 어떠한 이벤트가 발생할 때 비디오를 녹화할 수 있습니다 .

고장 해결

질문 : EZVIZ 앱으로 카메라를 추가할 때 “The device is offline.
(장비가 오프라인 상태입니다.)” 또는 “The device is not registered.
(장비가 등록되지 않았습니다.)” 라는 메시지가 표시됩니다.

답변 : 1. 카메라가 연결된 네트워크가 제대로 작동하고 있으며 라우터의 DHCP
가 활성화되어 있는지 확인합니다.
2. 네트워크 매개변수를 변경한 경우 설정을 초기화하려면 초기화 버튼을
5 초 동안 누릅니다.

질문 : 카메라가 온라인 상태이지만 모바일 폰이 경보 메시지를 수신할 수 없습
니다.

답변 : 1. 모바일 폰에서 EZVIZ 앱이 실행되고 있는지 확인합니다.
2. Android OS 모바일 폰의 경우 앱이 백그라운드로 실행 중인지 확인합
니다. iOS 폰의 경우에는 “Settings(설정) > Notification(알림)”에
서 메시지 푸시 기능을 활성화합니다.

질문 : USB 장치 또는 휴대용 배터리를 사용해 카메라에 전원을 공급할 수 있
습니까?

답변 : 안정적인 전원 공급을 위해 EZVIZ 표준 전원 어댑터를 사용하는 것이 좋
습니다.

 자세한 정보를 알아보시려면 www.ezvizlife.com 을 방문해 주십시오 .