

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezvizlife.com>).

### **Revision Record**

New release – September, 2021

### **Trademarks Acknowledgement**

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.


IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Indholdsfortegnelse

<b>Overblik</b> .....	<b>1</b>
1. Indholdet i pakken .....	1
2. Grundlæggende oplysninger .....	1
<b>Specifikationer</b> .....	<b>2</b>
<b>Indikator for luftkvalitet</b> .....	<b>2</b>
<b>Kontrolpanel</b> .....	<b>2</b>
<b>Installation</b> .....	<b>3</b>
<b>Fejlfinding</b> .....	<b>4</b>

# Overblik

## 1. Indholdet i pakken



Luftrensner (x 1)





Startvejledning (x 1)



Lovgivningsmæssige oplysninger (x 1)

## 2. Grundlæggende oplysninger



Filter




Bunddæksel


# Specifikationer

Beskrivelse	Luftrensere
Model	CS-EB250A
CADR-værdi	250 m <sup>3</sup> /t
Spænding	220-240 V, 50 Hz, 220-230 V, 60 Hz
Nominel effekt	45 W, 63 W
Bruttovægt/Nettovægt	4,3/3,4 kg
Mål	238 mm x 238 mm x 409 mm


## Indikator for luftkvalitet



Grøn



Gul



Rød











## Partikelindikator (PM2.5)

Luftkvalitet	Farveindikator
Godt	Grøn
Dårligt	Gul
Alvorligt	Rød

## Kontrolpanel




Ikone	Beskrivelse
	Tænd/sluk


	Tryk på Ventilatorknappen for at indstille den ønskede ventilatorhastighed. Dvaelstilstand: Støjsvag drift, ideelt om natten 1: Lav ventilatorhastighed 2: Middel ventilatorhastighed 3: Høj ventilatorhastighed
	Tryk på knappen Auto, hvis du vil lade enheden automatisk justere ventilatorhastigheden i overensstemmelse med luftkvaliteten i rummet.
	Tryk på Timerknappen for at indstille en periode for autosluk, så enheden konfigureres til automatisk at slukke efter et bestemt tidsrum. 1: Hvis du vælger dette, slukker enheden automatisk efter 1 time. 2: Hvis du vælger dette, slukker enheden automatisk efter 2 timer. 4: Hvis du vælger dette, slukker enheden automatisk efter 4 timer. 8: Hvis du vælger dette, slukker enheden automatisk efter 8 timer.
	Tænd eller sluk ionisator.
  	Når filteret når slutningen af dets anbefalede levetid, blinker "ON" som påmindelse om, at filteret skal skiftes snarest muligt. Når du har skiftet filteret, skal du holde knapperne "ON-F-T" inde i 5 sekunder for at nulstille filtertimeren. Du hører et langt bip, når filtertimeren er blevet nulstillet.
  	Hold knapperne "ON-F-AUTO" inde i 5 sekunder for at aktivere/deaktivere enhedens børnelås.

## Installation

1. Hold det roterende dæksel over bunden af produktet, og drej det mod uret i låseretningen for at tage filteret ud. Fjern posen om filteret, og sæt produktet tilbage i maskinen.



2. Når filteret er sat i maskinen, skal du matche trekanten på bunddækslet med trekanten på maskinen og dreje med uret for at stramme.



## Fejlfinding

Problem	Mulig årsag	Løsning
Kunne ikke tænde enheden	Stikket sidder ikke korrekt i stikkontakten	Sæt stikket sikkert fast i stikkontakten
	Frontdækslet sidder løst	Sørg for, at frontdækslet er korrekt lukket
Unormal lyd og lav luftstrøm under drift	Kontrollér, at plastposen om filteret er taget ud	Fjern plastposen fra filteret
	Kontrollér, om luftindtag eller luftudtag er blokeret	Sluk enheden, og fjern blokeringen
Sær lugt	Enheden er fabriksny	Lugten fortager sig snart
	Hvis nogen ryger	Lugten fortager sig efter et stykke tid
	Hvis filteret har absorberet for meget røg	Rens eller skift filtrene
	Det er på tide at udskifte filtrene	