

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezvizlife.com>).

Revision Record

New release – September, 2021

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.


IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Inhoudsopgave

Overzicht	1
1. Inhoud van de verpakking.....	1
2. Basis.....	1
Specificaties	2
Luchtkwaliteitsindicator	2
Bedieningspaneel	2
Installatie	3
Probleemoplossing	4

Overzicht

1. Inhoud van de verpakking



Luchtreiniger (x1)





Snelstartgids (x1)




Informatie met betrekking tot regelgeving (x1)

2. Basis



Filter




Deksel onderkant


Specificaties

Omschrijving	Luchtreiniger
Model	CS-EB250A
Reinigingscapaciteit rook	250 m ³ /h
Spanning	220-240 V~, 50 Hz; 220-230 V~, 60 Hz
Nominaal vermogen	45 W; 63 W
Brutogewicht/nettogewicht	4,3/3,4 kg
Afmetingen	238 x 238 x 409 mm


Luchtkwaliteitsindicator



Groen



Geel



Rood











Indicatie fijnstof (PM2.5)

Luchtkwaliteit	Kleur
Goed	Groen
Slecht	Geel
Ernstig	Rood

Bedieningspaneel




Pictogram	Omschrijving
	Aan-/uitzetten


	Tik op de toets Ventilatorsnelheid om de gewenste werkingssnelheid te selecteren. Slaapmodus: Geluidsarme werking, ideaal om te slapen 1: Werking op lage snelheid 2: Werking op gemiddelde snelheid 3: Werking op hoge snelheid
	Tik op de toets Automatische modus om de ventilatorsnelheid automatisch aan te passen aan de luchtkwaliteit in de ruimte.
	Tik op de toets Timer om het apparaat zo in te stellen dat het na een bepaalde tijd automatisch wordt uitgeschakeld. 1: Indien geselecteerd, schakelt het apparaat automatisch uit na 1 uur. 2: Indien geselecteerd, schakelt het apparaat automatisch uit na 2 uur. 4: Indien geselecteerd, schakelt het apparaat automatisch uit na 4 uur. 8: Indien geselecteerd, schakelt het apparaat automatisch uit na 8 uur.
	Schakel de ionisator in en uit.
  	Als het filter vervangen dient te worden, knippert "ION" om de gebruiker eraan te herinneren het filter zo spoedig mogelijk te vervangen. Houd na het vervangen van het filter de toets "ION-Filter-Timer" 5 seconden ingedrukt om de filtertimer te resetten, u hoort een lange pieptoon wanneer de filtertimer gereset is.
  	Houd de toets "Fan-Filter-AUTO" 5 seconden ingedrukt om het kinderslot in/uit te schakelen.

Installatie

1. Pak de onderkant van het apparaat vast en draai het deksel aan de bovenkant linksom om het te ontgrendelen en het filter te verwijderen. Verwijder de zak de filter en plaats de filter terug in het apparaat.



2. Nadat het filter in het apparaat is geplaatst, lijnt u de driehoekige vorm van het deksel aan de onderkant uit met de driehoek op het apparaat en draait u vervolgens het deksel rechtsom om deze te vergrendelen.



Probleemoplossing

Probleem	Mogelijke oorzaak	Oplossing
Kan het apparaat niet inschakelen.	Netsnoer niet goed in stopcontact gestoken.	Steek de stekker stevig in het stopcontact.
	De voorkant zit niet goed vast.	Zorg dat de voorkant goed gesloten is.
Abnormaal geluid en lage luchtstroom tijdens gebruik.	Controleer of de zake van de filter verwijderd is.	Verwijder de zak van filter.
	Controleer of de luchtinlaat en luchtuitlaat geblokkeerd zijn.	Schakel het apparaat uit en verwijder blokkerende voorwerpen.
Vreemde geur.	Het apparaat is nieuw.	De geur zal spoedig verdwijnen.
	Als iemand rookt.	De geur zal na een tijdje verdwijnen.
	Als het filter te veel rook heeft geabsorbeerd.	Reinig of vervang het filter.
	Het is tijd om het filter te vervangen.	