

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


#### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezvizlife.com>).

#### **Revision Record**

New release – September, 2021

#### **Trademarks Acknowledgement**

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

#### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.


IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Innholdsfortegnelse

<b>Oversikt</b> .....	<b>1</b>
1. Pakkens innhold.....	1
2. Grunnleggende funksjoner.....	1
<b>Spesifikasjoner</b> .....	<b>2</b>
<b>Luftkvalitetsindikator</b> .....	<b>2</b>
<b>Kontrollpanel</b> .....	<b>2</b>
<b>Installasjon</b> .....	<b>3</b>
<b>Feilsøking</b> .....	<b>4</b>

# Oversikt

## 1. Pakkens innhold



Luftrensers (x1)





Hurtigstartveiledning (x1)



Regulatorisk informasjon (x1)


## 2. Grunnleggende funksjoner




# Spesifikasjoner

Beskrivelse	Luftrensers
Modell	CS-EB250A
CADR for røyk	250 m <sup>3</sup> /t
Spenning	220–240 V~, 50 Hz; 220–230 V~, 60 Hz
Nominell strøm	45 W, 63 W
Brutto/netto	4,3/3,4 kg
Mål	238 mm 238 mm x 409 mm


## Luftkvalitetsindikator



Grønn



Gul



Rød


















### Indikasjon for små partikler (PM 2,5)

Luftkvalitet	Fargeindikasjon
Bra	Grønn
Dårlig	Gul
Alvorlig	Rød

## Kontrollpanel




Ikone	Beskrivelse
	Skru av/på


	Trykk på viftehastighetsknappen for å velge ønsket hastighet. Dvalemodus: Stille drift, ideelt for søvn 1: Bruk med lav hastighet 2: Bruk med middels hastighet 3: Bruk med høy hastighet
	Trykk på automodusknappen for at enheten skal justere viftehastigheten automatisk basert på luftkvaliteten i rommet.
	Trykk på tidtakerknappen for å stille inn en nedstengingstidaker for enheten, slik at den blir innstilt til å slå seg av automatisk etter en angitt periode. 1: Når du velger dette, skrus enheten av automatisk etter 1 time. 2: Når du velger dette, skrus enheten av automatisk etter 2 timer. 4: Når du velger dette, skrus enheten av automatisk etter 4 timer. 8: Når du velger dette, skrus enheten av automatisk etter 8 timer.
	Slå ioniseringsenheten av og på.
  	Når filteret når sluttet av den anbefalte levetiden, blinker «  » for å minne brukeren på at filteret må byttes så snart som mulig. Når du har byttet filteret, holder du inne «  -  -  »-knappen i fem sekunder for å tilbakestille tidtakeren for filteret. Deretter hører du en lang pipelyd når tidtakeren for filteret har blitt tilbakestilt.
  	Hold inne «  -  -  » i fem sekunder for å aktivere/deaktivere enhetens barnelåsfunksjon.

## Installasjon

1. Hold det vridbare dekelet fra undersiden av produktet, og vri det så mot klokken for å ta ut filteret. Fjern filterposen, og sett produktet tilbake inn i maskinen.



2. Når filteret har blitt satt inn i maskinen igjen, tilpasser du trekanten på bunndekselet til trekanten på maskinen og vrir det med klokken for å stramme det igjen.



## Feilsøking

Problem	Sannsynlig årsak	Løsning
Kunne ikke slå på enheten	Strømledningen er ikke satt riktig inn i stikkontakten	Koble enheten til på riktig måte
	Frontdekselet er ikke sikret	Sørg for at frontdekselet er ordentlig lukket
Unormal lyd og dårlig luftflyt under drift	Sjekk at filterposen er fjernet	Fjern filterposen
	Sjekk om luftinntaket eller luftutslippet er blokkert	Slå av enheten og fjern eventuelle hindringer
Merkelig lukt	Enheten ble tatt i bruk nylig	Lukten forsvinner snart
	Noen røyker	Lukten forsvinner etter en stund
	Hvis filteret har absorbert for mye røyk	Rengjør eller bytt filteret
	Det er på tide å bytte filteret	