

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.



About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the **EZVIZ™** website (<http://www.ezvizlife.com>).

Revision Record

New release – January, 2019

Trademarks Acknowledgement

 **EZVIZ™**,  **™**, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.


TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Pakkauksen sisältö



Kamera (x1)



Porauskaavio (x1)



Ruuvipakkaus (x1)



Pika-aloitusopas (x1)

Perustiedot



Nimi

LED-merkkivalo

Kuvaus

- Tasaisesti palava punainen: kamera käynnistyy.
- Hitaasti vilkkuva punainen: Wi-Fi-yhteys on katkennut.
- Nopeasti vilkkuva punainen: kameravika (esim. muistikortin virhe).
- Tasaisesti palava sininen: live-videota katsotaan EZVIZ-sovelluksessa.
- Hitaasti vilkkuva sininen: kamera toimii oikein.
- Nopeasti vilkkuva sininen: kamera on valmis Wi-Fi-yhteyden muodostukseen.

Objektiivi

Objektiivia voidaan säätää 15 astetta alaspäin.

Kameramoduuli

Kameramoduulia voidaan kääntää 10 astetta vasemmalle ja oikealle.


Nollaus-painike

Käynnistä uudelleen ja palauta kaikki parametrit oletusasetuksiin pitämällä painettuna 4 sekunnin ajan.

Asennus

- Suositeltu asennuskorkeus: 1,8–2,2 m maanpinnasta.
- Kamerassa on sisäänrakennettu muistikortti videotallennusta varten. Ylimääräistä SD-korttia ei tarvitse asentaa.


1. Katkaise virta katkaisijasta.



- Jos et tiedä katkaisijan sijaintia tai et osaa katkaista virtaa, ota yhteyttä valtuutettuun sähköasentajaan.
- Pidä katkaisija pois päältä koko asennusprosessin ajan.


2. Irrota asennuspohja kamerasta.

Kierrä pohjaruuvi auki käyttäen ruuvimeisseliä (ei sisälly pakkaukseen) ja vedä asennuspohja irti kamerasta.




3. Asenna asennuspohja.

- Aseta porauskaavio pinnalle, johon haluat kiinnittää pohjan.
- **(Vain betoniseinä)** Pora ruuvinreiät kaavion mukaisesti ja aseta reikiin ankkurit.
- Vedä johdot seinästä porauskaavion ja asennuspohjan kumin läpi.
- Kiinnitä asennuspohja ruuveilla.



4. Liitä johdot.


- Liitä nollajohto (N), maadoitusjohto (GN) ja jännitteellinen johto (L) yksi kerrallaan.
- Kiinnitä ne käyttäen ruuvimeisseliä.



- 1 Jännitteellinen johto (L)
- 2 Nollajohto (N)


5. Työnnä kamera asennuspohjaan.

- Kiinnitä asennuspohjan pohja soljella kameraan.
- Paina asennuspohja ja kamera yhteen.
- Kiristä kameran päällä oleva pohjaruuvi.




6. Säädä kameramoduulin kulma.

Voit säätää kameramoduulin vaaka- ja pystykulmaa tarpeen mukaan.




7. Kytke katkaisijan virta takaisin päälle.



8. Varmista, että kamerassa on virta.

Virran palauttamisen jälkeen kamera on valmis asennettavaksi, kun valo palaa ja kameran etuosassa oleva LED-merkkivalo vilkkuu nopeasti sinisenä.



Määritys

1. Hanki EZVIZ-sovellus


- Yhdistä matkapuhelimesi Wi-Fi-verkkoon.
- Lataa ja asenna EZVIZ-sovellus hakusanalla "EZVIZ" App Storesta tai Google Play™ -kaupasta.
- Käynnistä sovellus ja rekisteröi EZVIZ-käyttäjätili.

2. Lisää kamera EZVIZ-tiliin

- Kirjaudu tilillesi EZVIZ-sovelluksella.
Siirry QR-koodin skannausnäkyeseen napauttamalla aloitusnäytön oikeassa yläkulmassa olevaa "+"-symbolia.



- Skannaa tämän pika-aloitusoppaan kannessa tai kamerasuojassa oleva QR-koodi.



- Tee Wi-Fi-määritys loppuun käyttämällä EZVIZ-sovelluksen ohjattua toimintaa.

-  Jos haluat vaihtaa kamerasi Wi-Fi-yhteyden, pidä nollauspainiketta painettuna 4 sekunnin ajan ja toista edellä esitetyt vaiheet.

ALTISTUMINEN RADIOTAAJUUKSILLE

Tähän radiolaitteeseen sovellettavat taajuuskaistat ja lähetetyn tehon (säteilevän ja/tai voimalinjaperäisen) nimellisrajat ovat seuraavat:

Kaista	Wi-Fi 2,4 GHz
Taajuus	2,4–2,4835 GHz
Lähetysteho (EIRP)	100 mW

-  Katso lisätietoja osoitteesta www.ezviz.eu.