

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezviz.com>).

Revision Record

New release – January, 2025

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Table of Contents

Instruction.....	1
Packing List	2
Overview	3
1. Front Panel.....	3
2. Rear Panel.....	4
Installation	6
1. View Installation Video	6
2. Fully Charge the Battery	6
Install Battery	7
Set the Direction of Door Opening.....	7
Create a New Administrator.....	7
Get the EZVIZ App	8
Add the Lock to EZVIZ	8
Lock Settings	9
1. Keypad.....	9
2. Enter Menu.....	9
3. Menu Index	10
4. Add Administrators/Users	10
5. Add Human face.....	11
6. Add Palm Vein.....	12
7. Add Fingerprint	13
8. Add Passcode	13
9. Delete Administrators/Users	14
10.Look Up to the System Information.....	14
11.Enter Pairing Mode.....	14
Multiple Unlock Methods.....	15
1. Face Recognition Unlock	16
2. Fingerprint Unlock.....	16
3. Passcode Unlock.....	16
4. Mechanical Key Unlock	17

Multiple Lock Methods	17
1. Outside Lock	17
2. Inside Lock.....	17
3. Countdown Lock.....	17
Operation and Management.....	18
1. Emergency Unlock.....	18
2. Alarms	18
3. Restore to Factory Settings	18
4. One-time Mute function	18
Operations on the EZVIZ App.....	19
Maintenance	20
1. Daily Maintenance.....	20
2. FAQ	20
Initiatives on the Use of Video Products	22

Instruction

- The installation of EZVIZ Smart Lock (hereinafter referred as to "lock") impacts its normal operation and service life. It is recommended to let professionals install, and drill hole for lock set in accordance with hole templet in appendix.
- It is recommended to remove the lock if your house is under decoration, and reinstall it after decoration in case of lock damage and service life reduction.
- Please note that disinfectant may cause damage to the lock body.
- Please note that corrosive cleaning fluids may damage or corrode the lock body.
- Avoid installing the lock in a completely open-air scene.
- Once initialized completed, the lock will clear all user information. After lock installation and configuration, please add human face, fingerprint, or passcode as needed.
- When battery voltage is low after using for a while, low voltage alarm alerts. Charge battery timely.
- If you leave home or do not use lock for a long time, keep mechanical key with you, and do not leave it indoors. You should take battery out to ensure lock service life.
- Considering that the lock is put in an open environment, we suggest you pay attention to the safety in use, including keep properly small parts like the mechanical key. You should check the surrounding environment before unlocking and updating your passcode settings on time as well in case of any danger of illegal stealing or copying of your unlocking information.
- The bio recognition technology in this product operates ENTIRELY LOCALLY on the product that you control and manage yourself, and only serves the sole purpose of supporting your decision of unlocking. During the whole course, the saved data always only contains technical value, i.e. the biometric data obtained from the templates you proactively provided in advance (such as facial images, fingerprint template, palm vein template),which cannot be used to reconstruct the original data.
- For users with flat or thin fingerprint, it is recommended to use thumb to register fingerprint for increasing success rate, and register more than one fingerprint each user. Each user supports a maximum of 5 fingerprints.
- The lock accommodates up to 50 human faces, 50 palm veins, 50 fingerprints, and 50 passcodes.


Packing List

NO.	Part Name	Quantity
1	Front Panel	×1
2	Rear Panel	×1
3	Hole Template	×1
4	Lock Body	×1
5	Lock Body Screw Bag	×1
6	Standard Screw Bag	×1
7	Battery	×1
8	Key Bag	×1
9	Stickers	×1
10	Regulatory Information	×1
11	Quick Start Guide	×1

 This manual applies to both the 6068 and 5085 version, with illustrations based on 6068 lock body, due to the similarity in functionality.


Overview


1. Front Panel



2. Rear Panel

• 6068 Version





Installation


1. View Installation Video

Please tap  to watch the installation video.



2. Fully Charge the Battery


Connect the battery (included in the package) to a power outlet via power adapter.



- Before the first time use, please charge the lithium battery.
- Before charging the battery, please remove it from the rear panel.
- The power outlet shall be installed near the power adapter and shall be easily accessible.

Install Battery


1. After installation, remove the cover of battery slot from the rear panel.
2. Install the lithium battery (included in the package) into the battery slot.
3. Place the cover back.



Set the Direction of Door Opening

After the installation is completed, please follow the voice prompt to set the direction of door opening.

1. Press "√" to proceed with the process.
2. "1" "2" on the keypad light up.
 - Press "1" to set the door to "right-opening".
 - Press "2" to set the door to "left-opening".




Create a New Administrator

Please follow the voice prompt to create the first administrator.


1. Touch the keypad area to activate the lock.
2. "√" "√" on keypad light up. Press "√" to exit and press "√" to add an administrator.
3. Enter a passcode with 6-10 digits, and press "√" to confirm.
4. Repeat the passcode once again, and press "√" to confirm.

- 6-10 consecutive or repeated numbers are not allowed.
- 6-10 consecutive digits, such as 123456/654321.
- 6-10 repeated digits, such as 111111.



Get the EZVIZ App

1. Connect your mobile phone to 2.4GHz Wi-Fi (suggested).
2. Download and install the EZVIZ app by searching for “EZVIZ” in the App Store or Google Play™.
3. Launch the app and register an EZVIZ user account.



- i** If you have already used the app, please make sure that it is the latest version. To find out if an update is available, go to the app store and search for "EZVIZ".

Add the Lock to EZVIZ

- i** The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

Please add lock to EZVIZ by following steps:


1. Log in to your EZVIZ app account.
2. On the Home screen, tap “+” on the upper-right corner to go to the Scan QR Code interface.
3. Press the button at the bottom of the rear panel to remove the cover of the rear panel.
4. Press and hold the SET button on the rear panel until the lock sends a voice prompt and the LED Indicator starts flashing, which means the pairing mode has been enabled.
5. Scan the QR code displayed on the screen.
6. Follow the EZVIZ app wizard to finish the Wi-Fi configuration, add the lock to EZVIZ app account.



Lock Settings

- Before setting, please ensure you have added an administrator.
- Please remove protective film from lock before the first use.
- After waking up the keypad area, it will automatically turn off after approximately 20 seconds if no operation is detected.

1. Keypad




Icon	Description
	Number key
	Cancel, return or exit
	Confirm
	Leaving-home mode
	Doorbell
	Low-battery indicator

2. Enter Menu

- Please follow these steps for settings.
- **In initial state, follow these steps for settings.**

1. Touch the keypad area of the front panel to activate the lock.
2. "↶" "√" on keypad light up, press "√" add an administrator.
3. "1" "2" "3" "4" "5" "↶" on keypad will light up.




• In non-initial state, follow these steps for settings.

- 1. Press the SET button once on the rear panel.
- 2. When the keypad of the front panel is light up, verify with administrator's authentication key.
- 3. "1" "2" "3" "4" "5" "⏏" on keypad will light up.



3. Menu Index

i The menu here is for reference only.



4. Add Administrators/Users

- 1. Press the SET button once on the rear panel.
- 2. When the keypad of the front panel is light up, verify with administrator's authentication key.
- 3. Press "1" to add an administrator, or press "2" to add a user.

Role	Unlock the door	Enter the Menu, and set the lock
Administrator	√	√
User	√	X

Ordinary users can only unlock the door after entering the opening method; the administrator can not only unlock the door, but also log in to the menu to add and delete users and operate other settings.

i When you add an administrator or a user, the figures corresponded to the user number will light up from 001 by default (for example, to user number 001, the three numbers 001 will slow-flash once in sequence).

5. Add Human face

i Add up to 3 human faces per user.

1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "1" to add a human face.
4. Follow the voice prompt to add a human face.



- i** • Please stand directly in front of the front panel of the lock and keep an arm's length from the lock, (being outside this distance may cause face recognition to fail).
- Follow the voice prompt to complete face recognition (please refer to the actual voice content in case of adjustment), as shown in the figure below.
- It is essential to ensure that there is no obstruction on the face during this process.
- Please refrain from shaking or moving your body during the process; otherwise, it may lead to fail.
- After adding a face, you can use face recognition to unlock the door.

- 1** Please look straight at the lock. **2** Please raise the head slightly. **3** Please lower the head slightly.




- 4** Please slightly turn to left. **5** Please slightly turn to right. **6** Operation successful.



6. Add Palm Vein



i Add up to 2 palm vein keys per user.

1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "2" to add a palm vein.
4. Follow the voice prompt to add a palm vein.




i Please read the following instructions carefully to add your palm vein.

- 1** The valid area for palm vein recognition is the center of the palm.
- 2** When the red light at the upper part of the lock turns on, you can start adding or recognizing.



- 3** It is recommended to keep your palm vertically with the front panel and touch the red light in the palm vein recognition module.
- 4** Lift your palm to align the palm with the red light, with your palm naturally relaxed, and start adding or recognizing.
 - i** Keep your palm at a distance of about 20cm. A child's palm can be at a properly closer distance of about 10cm.



7. Add Fingerprint

- Add up to 5 fingerprints per user.
- Place your finger to fully cover the fingerprint reader, avoiding excessive pressure or tilted angles.

1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "1" to add an administrator, or press "2" to add a user.
4. Press "3" to add a fingerprint.



- The same fingerprint cannot be added again.

8. Add Passcode

- Add up to 1 passcode per user.

1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "1" to add an administrator, or press "2" to add a user.
4. Press "4" to add a passcode.
5. Enter a passcode with 6-10 digits. When the passcode input key ≥ 6 digits, "✓" lights up at this time, press "✓" to confirm.
6. Repeat the passcode once again, press "✓" to confirm, accompanied by a success beep, the passcode is successfully added.



- 6-10 consecutive or repeated numbers are not allowed.
 - 6-10 consecutive digits, such as 123456/654321.
 - 6-10 repeated digits, such as 111111.

9. Delete Administrators/Users


1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "3" to delete an administrator/a user.
4. Enter the user number and press √.



- The last administrator can not be deleted.
- If you pressed a wrong user number, you will see the user number light up one by one, accompanied by a failure beep. Press "↶" to return to last step, or enter the right user numbers to delete again.
- When there is only one user left, and you operate to delete it, you will see the user number light up one by one, accompanied by a failure beep.

10. Look Up to the System Information


1. Press the SET button once on the rear panel.
2. When the keypad of the front panel is light up, verify with administrator's authentication key.
3. Press "5" to look up to the system information of the lock.
4. The lock will broadcast the system information.



- The lock will broadcast the lock serial number, the current device version and verification code in English in turn, press "↶" to return to the previous level. Or the system will return to the previous level automatically after finish the broadcast.

11. Enter Pairing Mode

Press and hold the SET button on the rear panel until the lock sends a voice prompt and the keypad number 0 flashes to enter pairing mode. Please follow the system guide to finish the pairing in 3 minutes.



- The system will exit the pairing mode automatically after 3 minutes.

Multiple Unlock Methods

Icon	Unlock Method
	Face recognition unlock
	Palm vein unlock
	Fingerprint unlock
	Passcode unlock
	Mechanical key unlock
	Bluetooth key unlock
	Remote unlock



- When opening the door by mechanical key, insert and rotate the key.
- Please touch the keypad area to activate the lock before opening the door by passcode.
- For your privacy security, it is recommended to change passcodes and clean keypad area regularly in case of remaining marks.



- This product has security protection function, face/palm vein/fingerprint/passcode recognition error number reaches 5 times continuously in 5minutes, the system will be locked forcibly for 3 minutes.
- The system will be unlocked automatically after 3 minutes.
- You can turn off this function in EZVIZ app.


1. Face Recognition Unlock

Automatically triggered

When the face is close to the detection range of the lock, the lock will automatically recognize the face and unlock the door.

Manually triggered

You need to touch the keypad to activate the lock in order to trigger the face recognition function. In face recognition mode, the face recognition IR light will flash, as shown in the figure below.



2. Fingerprint Unlock


Put your finger on the fingerprint reader, the lock will verify the fingerprint and unlock the door.



3. Passcode Unlock

i The product has protected with Anti-Peeping Passcodes. In case someone is watching you entering a passcode, you can add extra-long digits before or after your original code to make it complex, while still being able to unlock.


1. Touch the keypad area to activate the lock.
2. Enter the corresponding 6-10 digit valid passcode ,and press "√" to confirm.
3. The lock will verify the passcode and unlock the door.



4. Mechanical Key Unlock

 Please keep the mechanical key properly for further use.

1. Open the cover of the mechanical keyhole.
2. Insert the mechanical key and rotate it, the door will be unlocked.



Multiple Lock Methods

1. Outside Lock

When the door is opened from the inside, the “√” on the front panel’s keypad will light up, and press “√” to confirm the locking.

2. Inside Lock

After closing the door, press the “electronic locking button” on the rear panel to confirm the locking.

3. Countdown Lock


Open the “countdown locking” function in the EZVIZ app. After this function is enabled, the door lock will automatically lock after the countdown ends.

Operation and Management

1. Emergency Unlock

When battery is out of power, connect the emergency power supply interface of the front panel with power bank to charge the lock through Type-C power cable and then unlock the door.

 Video is unavailable when battery power drops below 20%.



2. Alarms

1. Anti-tamper Alarm

Once being dismantled by force, the lock will send out alarm lasting about one minute.

2. System Locked Alarm

Verify with wrong face, palm vein, fingerprint or passcode 5 times in a row, the system will be locked for 3 minutes. You can unlock it in the EZVIZ app.

3. Low Battery Warning

Once battery voltage is low, the voice prompt will remind you to charge battery.

3. Restore to Factory Settings

1. Remove the battery cover of rear panel and take out the battery.
2. Press the SET button for 5 seconds, meanwhile put back battery in the battery slot.
3. Release the SET button and press ✓ to confirm after voice prompts.

4. One-time Mute function


1. Touch the keypad area to wake up the keypad.
2. Press and hold "0" until the keypad flashes twice to indicate the function is on.

 • When the one-time mute function is enabled, the door goes into silent mode.
• The lock will automatically exit this mode when it has been unlocked by verification with the added face, palm vein, fingerprint or passcode from the outside.

Operations on the EZVIZ App

 The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

When you launch the EZVIZ app and tap your lock, you can view and manage the lock as needed on the homepage.



Parameter	Description
	Tap the icon to view or change the device settings.
Battery	You can see the battery remaining capacity here.
Signal	You can see the Wi-Fi signal strength of the lock here.
Bluetooth	You can see the Bluetooth connection status.
Live	Tap to view the outdoor video.
Bluetooth Unlock/Unlock	Tap to unlock the lock via Bluetooth/remote unlock.  To remotely unlock the door, please disable the Bluetooth and enable Remote Unlock in Settings > Unlock Settings.
User Management	You can tap to manage the users here.  After adding a user, you can also add unlocking methods for that user, such as face, fingerprint, digital code and duress passcode. Please note that the unlocking method needs to operate on the lock.
Temporary Passcode	Tap to generate a temporary access code for visitors to open the door.
Bluetooth Key	Tap to generate a Bluetooth pairing code for visitors to open/lock the door via Bluetooth.
All Events	Check all events happened to the lock.

Maintenance

1. Daily Maintenance

- Do not clean the lock body with disinfectants, as this may cause damage.
- Do not put corrosive materials near the lock to avoid lock damage and impacting its gloss.
- If door deforms, it increases friction that combined latch bolt entering the box strike plate and bolt cannot extend fully. At this time, adjusting strike plate position is needed.
- Charge the battery immediately once battery voltage is low to ensure the normal use of the lock.
- Keep the mechanical key properly.
- Ask professionals to check the lock if it is not flexible.
- Keep lubricant in the rotating part of the lock to keep it rotate smoothly and prolong its service life.
- It is recommended to check the lock once every six months or one year, and check whether fixed screws are loose.
- Apply a small amount of graphite powder or pencil powder into lock cylinder slot to ensure the key is inserted and removed smoothly on regular basis (one year or six months). However, do not apply any grease to lubricate in case of grease sticking to the pin tumbler spring.

2. FAQ

Problem	Cause	Solution
Door cannot be opened normally through verifications by face recognition, palm vein, fingerprint, or passcode.	Lock installation issue	Please have professionals recheck the installation.
	User authority is not within the validity period.	Please use face, palm vein, fingerprints or passcodes of other users, or update the user validity period through EZVIZ app.
Door cannot be opened with mechanical key	Incorrect mechanical key	Use the correct mechanical key.
	Lock cylinder is damaged.	After opening the door, please have professionals check and replace damaged components.
	The mechanical key cannot be fully inserted.	
No response from fingerprint reader	Fingerprint reader is damaged.	Please have professionals recheck the installation.
The lock is always open.	Installation error	Please have professionals recheck the replacement.
	Clutch is damaged.	Please have professionals recheck the installation.
Door cannot be opened with the handle on the rear panel.	Installation issue	Please have professionals recheck the installation.

Problem	Cause	Solution
Unable to connect your mobile phone Bluetooth.	Mobile phone Bluetooth is disabled.	Please enable your mobile phone Bluetooth and try to connect again.
	The distance between the lock and your mobile phone is out of Bluetooth range (50 m).	Please get closer to the door lock and try again.
	Other reasons	a. Try again after restarting the Mobile phone Bluetooth. b. Try again after exiting and re-entering the EZVIZ app.
Users, palm vein, fingerprints and passcodes cannot be added on the EZVIZ app.	The network environment is unstable	Please connect the lock Bluetooth first, then add them in the user management on the EZVIZ app
The device is often offline.	The lock is not connected to the network.	Please connect the lock to a network with better and more stable signal.
Fast battery power consumption.	Network environment is unstable.	Please turn off the Wi-Fi switch on EZVIZ app.
		Please change to a stable network signal.

 For additional information about the device, please refer to www.ezviz.com.

Initiatives on the Use of Video Products

Dear Valued EZVIZ Users,

Technology affects every aspect of our life. As a forward-looking tech company, we are increasingly aware of the role technology plays in improving efficiency and quality of our life. At the same time, we are also aware of the potential harm of its improper usage. For example, video products can record real, complete and clear images, therefore they hold great values in representing facts. Nevertheless, improper distribution, use and/or processing of video records may infringe on the privacy, legitimate rights and interests of others.

Committed to innovating technology for the good, we at EZVIZ hereby earnestly advocate that every user shall use video products properly and responsibly, thus to collectively create a positive environment where all related practices and usage comply with applicable laws and regulations, respect individuals' interests and rights, and promote social morality.

Here are EZVIZ's initiatives that we'd appreciate your attention:

1. Each individual possesses a reasonable expectation of privacy, and the use of video products should not be in conflict with such reasonable expectation. Therefore, a warning notice which clarifies the monitoring range should be displayed in a reasonable and effective manner, when installing video products in public areas. For non-public areas, the rights and interests of people involved shall be evaluated thoughtfully, including but not limited to, installing video products only after obtaining the consent of the stakeholders, and not installing highly-invisible video products without other's knowledge.
2. Video products objectively records footage of real activities within specific time and space. Users shall reasonably identify the people and rights involved in this scope in advance, to avoid any infringement of portrait, privacy or other legal rights of others while protecting themselves through video products. Notably, if you choose to enable the audio recording function on your camera, it will capture sounds, including conversations, within the monitoring range. We highly recommend a comprehensive assessment on the potential sound sources in the monitoring range, so as to fully understand the necessity and the reasonableness before you turn on the audio recording function.
3. Video products in use will consistently generate audio or visual data from real scenes –possibly including biometric information such as facial images – based on the user's selection of product features. Such data can be used or processed to use. Video products are only technological tools that do not and cannot humanly practice legal and moral standards to guide lawful and proper use of data. It is the methods and purposes of the people who control and use the generated data that make a difference. Therefore, data controllers shall not only strictly abide by applicable laws and regulations, but also fully respect non-obligatory rules including international conventions, moral standards, cultural norms, public order and local customs. Furthermore, we should always prioritize the protection of privacy and portrait rights, and other reasonable interests.
4. The video data continuously generated by video products carries the rights, values and other demands of various stakeholders. Thus, it is extremely crucial to ensure data security and shield the products from malicious intrusions. Every user and data controller shall, undertake all reasonable and necessary measures to maximize product and data security, avoiding data leakage, improper disclosure or misuse, including but not limited to, setting up access control, selecting a suitable network environment where video products are connected, establishing and constantly optimizing network security.
5. Video products have made great contributions to enhance the safety of our society, and we believe that they will continue to play a positive role in various aspects of our daily life. Any attempt to abuse these products to violate human rights or engage in unlawful activities contradicts the very essence of the value in tech innovation and product development. We encourage every user to establish your own methods and rules to evaluate and monitor the use of video products, so as to ensure that these products are always used properly, thoughtfully and with goodwill.