

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd.: ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezviz.com>).

Revision Record

New release – January, 2024

Trademarks Acknowledgement

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES. IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Table of Contents

Instruction.....	1
Packing List	2
Overview	3
1. Front Panel.....	3
2. Rear Panel.....	3
Installation	4
1. Installation Scenarios.....	4
2. Installation Diagram	4
3. View Installation Video	5
4. Install Completely.....	5
Install Battery	6
Get the EZVIZ App.....	6
Lock Settings	8
1. Keypad	8
2. Enter Menu.....	9
3. Menu Index	10
4. Add Administrators/Users	12
5. Add Fingerprint (Optional)	12
6. Add Passcode	13
7. Add Proximity Card (Optional)	14
8. Delete Administrators/Users	14
9. Look Up to the System Information	15
10. Clear Network Information.....	16
11. Finish the Wi-Fi Configuration	16
Multiple Unlock Methods	17
1. Fingerprint Unlock.....	17
2. Passcode Unlock.....	18
3. Card Unlock.....	18
4. Mechanical key Unlock.....	18
5. Inside Unlock	19
Multiple Locking Methods	19
1. Auto-lock	19
2. Countdown locking.....	19

3. Outside locking 19

4. Inside locking 19

Operation and Management.....20

1. Emergency Unlock..... 20

2. Alarms 20

3. Restore to Factory Settings 20

4. One-time Passcode 20

5. Super Power-saving Mode..... 20

6. One-time Mute function 20

Operations on the EZVIZ App21

1. Homepage..... 21

2. Settings..... 22

Maintenance.....23

1. Daily Maintenance..... 23

2. FAQ 23

3. Replaceable alkaline dry cells 24

4. Information for Private Households 24

Instruction

- The installation of EZVIZ Smart Lock (hereinafter referred as to "lock") impacts its normal operation and service life. It is recommended to let professionals install, and drill hole for lock set in accordance with hole templet in appendix.
- It is recommended to remove the lock if your house is under decoration, and reinstall it after decoration in case of lock damage and service life reduction.
- Please note that disinfectant may cause damage to the lock body.
- Once initialized completed, the lock will clear all user information. After lock installation and configuration, please add fingerprint, passcode or card as needed.
- When battery voltage is low after using for a while, low voltage alarm alerts. Replace battery timely and pay attention to positive and negative poles.
- If you are away from home or have not used the lock for a long time, it is recommended to remove the battery to prolong the life of the lock.
- Considering that the lock is put in an open environment, we suggest you pay attention to the safety in use, including keep properly small parts like the proximity card. You should check the surrounding environment before unlocking and updating your passcode and proximity card settings on time as well in case of any danger of illegal stealing or copying of your unlocking information.
- For users with flat or thin fingerprint, it is recommended to use thumb to register fingerprint for inceasing success rate, and register more than one fingerprint each user. Each user supports a maximum of 5 fingerprints.
- For the [Fingerprint-Card-Passcode-Version](#): The lock accommodates up to 50 fingerprints, 50 passcodes and 50 cards.
- For the [Passcode-Version](#): The lock accommodates up to 50 passcodes.
- The bio recognition technology in this product operates ENTIRELY LOCALLY on the product that you control and manage yourself, and only serves the sole purpose of supporting your decision of unlocking. During the whole course, the saved data always only contains technical value, i.e. the biometric data obtained from the templates you proactively provided in advance (such as facial images, fingerprint template, palm vein template),which cannot be used to reconstruct the original data.

Packing List



or




Fingerprint-Card-Passcode-Version

Passcode-Version

Front Panel (x1)



Rear Panel (x1)



Screw Kit (x1)



Mounting Bracket (x1)
(For front panel)



AA-sized Battery (x4)




* Proximity Card (x2)



Lock Cylinder Kit (x1)



Lock Body Kit(x1)



Hole Templet (x1)



Regulatory Information (x1)



Quick Start Guide (x1)

- The appearance of the Lock is subject to the actual one you have bought.
- The proximity cards are only included in the package of the **Fingerprint-Card-Passcode-Version**.


Overview

Here we take the Fingerprint-Card-Passcode-Version for example.

1. Front Panel



2. Rear Panel




i The appearance of the Lock is subject to the actual one you have bought.

Installation

1. Installation Scenarios

The lock can be installed on doors with a direction of opening to the left or right, in or out. It is placed inside the environment and check its scenario according to the following illustration.

- i Attention:** The lock is not suitable for external environments. Be sure to install your lock in an internal environment, protecting it from the sun and rain.




- i Important:** Avoid installing the lock near the upper and lower extremities of the door to avoid the lever effect or hinder its full operation. This product does not replace your door handle. Follow the instructions below according to your installation scenario.

2. Installation Diagram

- i Suggestion:** Carefully check the lock diagram in the drilling template.

To make the necessary perforations and install the equipment correctly, follow the process according to your installation scenario.



3. View Installation Video

Please tap  to watch the installation video.



4. Install Completely




Inside the Door



Outside the Door

Install Battery

1. After installation, remove the cover of battery slot from the rear panel.
2. Install 4*AA-sized batteries into the battery slot.
3. Place battery cover back.



Battery Safety Warnings and Instructions

WARNING: Risk of explosion if batteries are incorrectly replaced. Please read and follow all battery instructions carefully.


- Use only specified batteries: When replacing, you **MUST** use four (4) new, high-quality alkaline AA (LR6, 1.5V) batteries. To prevent explosion, ensure correct voltage and polarity. Do not mix alkaline batteries with other types (e.g., carbon-zinc, lithium, or rechargeable NiMH).
- Do not mix old and new batteries: Always replace all four batteries at the same time.
- Observe correct polarity: Do not reverse the (+) and (-) terminals when inserting batteries.
- Remove batteries during long-term storage: If the smart lock will not be used for an extended period, remove the batteries to prevent leakage and damage to the device.
- Do not recharge or expose to heat: Never recharge non-rechargeable alkaline batteries. Do not dispose of them in fire or expose them to excessive heat.
- Proper Disposal: Dispose of used batteries according to local environmental laws and recycling regulations. Do not dispose of them with regular household waste.
- Replacement Specifications: When replacing, use batteries of the same model or equivalent specifications (refer to ["Replaceable alkaline dry cells"](#)).

Get the EZVIZ App

Before downloading the app:

- If the app is already installed, verify that it is the latest version by checking for updates in your app store.
- If the app is not installed, follow the steps below to download it.

1. Connect your mobile phone to a 2.4GHz Wi-Fi (suggested).
2. Download the EZVIZ App by searching "EZVIZ" in the App Store or Google Play™.
3. Register an EZVIZ account and log in to the app.




Add the Lock to EZVIZ


i The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

Please add lock to EZVIZ by following steps:

1. Log in to your EZVIZ app account.
2. On the Home screen, tap “+” on the upper-right corner to go to the Scan QR Code interface.
3. Press and hold the SET button on the rear panel until the lock sends a voice prompt and the keypad number 0 flashes to enter pairing mode.



4. Scan the QR code on the back of the battery cover.




5. Follow the EZVIZ app wizard to add the lock to EZVIZ app account.

Lock Settings

Then you can set the lock as needed.

- Please remove protective film from lock before the first use.
- Please note that disinfectant may cause damage to the lock body.

1. Keypad



Icon	Description
	number key
	cancel, return or exit
	confirm
	leaving-home mode key
	card swiping area (Optional)
	doorbell
	low-battery indicator

2. Enter Menu

1

- Please follow these steps for settings.
- Here we will take the [Fingerprint-Card-Passcode-Version](#) as an example.

• In initial state, follow these steps for settings.

1


Touch the keypad area to activate the lock.



2

"↩" "✓" on keypad light up.

- Press "↩" to exit.
- Press "✓" add an administrator.



3

"1" "2" "3" "↩" on keypad light up.

- Press "1" to add a fingerprint.
- Press "2" to add a passcode.
- Press "3" to add a card.
- Press "↩" to exit/ return.



• In non-initial state, follow these steps for settings.


1

Short press the SET button once.



2

When the keypad is light up, verify with administrator's fingerprint, passcode or card.



3


"1" "2" "3" "4" "5" "↩" on keypad will light up.



3. Menu Index

i The menu here is for reference only.


• For the **Fingerprint-Card-Passcode** Version.



• For the **Passcode** Version.





Enter the Menu



4. Add Administrators/Users

- ❶ Enter the menu. (For detailed operations, please refer to "Enter Menu")
- ❷ Press "1" to add an administrator, or press "2" to add a user.





Role	Unlock the door	Enter the Menu, and set the lock
Administrator	✓	✓
User	✓	X

Ordinary users can only unlock the door after entering the opening method; the administrator can not only unlock the door, but also log in to the menu to add and delete users and operate other settings.



- ❶ When you add an administrator or a user, the figures corresponded to the user number will light up from 001 by default (for example, to user number 001, the three numbers 001 will slow-flash once in sequence).

5. Add Fingerprint (Optional)


- ❶ • Add up to 5 fingerprints per user.
• Only the [Fingerprint-Card-Passcode-Version](#) supports this function.
- ❷ Enter the menu. (For detailed operations, please refer to "Enter Menu")
- ❸ Press "1" to add an administrator, or press "2" to add a user.



- ❹ Press "1" to add a fingerprint.
- ❺ When "1" lights up, touch the fingerprint reader and repeat the operation 6 times, 1~6 light up one by one, accompanied by a success beep, the fingerprint is successfully added.
- ❻ • Press "1" to add fingerprints continuously.
• Press the key to return to the previous level.
• Press the SET button to exit.





- i** When the fingerprint has been added, and you operate to add it again, the number “1, 3, 5, 7, 9” (seems like a X) on the keypad will light up and flash 2 times, accompanied by a failure beep.



6. Add Passcode

- i** Add up to 1 passcode per user.




- ①** Enter the menu. (For detailed operations, please refer to “Enter Menu”) **②** Press “1” to add an administrator, or press “2” to add a user.



- ③** Press “2” to add a passcode.

- ④** Enter the corresponding 6-10 digit valid passcode .when the passcode input key ≥ 6 digits, “√” lights up at this time, press “√” to confirm.



- ⑤** Repeat the passcode once again, press “√” to confirm, accompanied by a success beep, the passcode is successfully added.



7. Add Proximity Card (Optional)

- Add up to 1 proximity card per user.
- Only the [Fingerprint-Card-Passcode](#)-Version supports this function.



❶ Enter the menu. (For detailed operations, please refer to "Enter Menu") **❷** Press "1" to add an administrator, or press "2" to add a user.



❸ Press "3" to add a card.

❹ Place the unrecorded proximity card on the card swiping area.



- ❺**
- Press "✓" to confirm.
 - Press "↶" to return to the previous level.



8. Delete Administrators/Users


❶ Enter the menu. (For detailed operations, please refer to "Enter Menu") **❷** Press "3" to delete an administrator/a user.

❸ Enter the user number and press ✓.






- If you pressed a wrong user number, the number "1, 3, 5, 7, 9" (seems like a X) on the keypad will light up and flash 2 times, accompanied by a failure beep. Press "↵" to return to last step, or enter the user numbers to delete again.





- When there is only one user left, and you operate to delete it, the number "1, 3, 5, 7, 9" (seems like a X) on the keypad will light up and flash 2 times, accompanied by a failure beep.



9. Look Up to the System Information


- 1 Enter the menu. (For detailed operations, please refer to "Enter Menu")
- 2 Press "4" to look up to the system information of the lock.
- 3 The lock will broadcast the system information.




- The lock will broadcast the lock serial number, the current device version and verification code in English in turn, press "↵" to return to the previous level.

10. Clear Network Information

- 1 Enter the menu. (For detailed operations, please refer to "Enter Menu")
- 2 Press "5" to clear the network information.




- 3
 - Press "✓" to confirm.
 - Press "↶" to return to the previous level.



- i When the network information is cleared, and you want to add the lock to your EZVIZ app account, you need to reconfigure the network.

11. Finish the Wi-Fi Configuration

Press and hold the SET button on the rear panel, until the lock sends a voice prompt and the keypad number 0 starts flash accompanied by a beep which means the Wi-Fi configuration mode is turned on.



Please follow the system guide to finish the network information in 3 minutes.

- i The system will exit the network configuration mode automatically after 3 minutes.

Multiple Unlock Methods


Icon	Description
	Fingerprint unlock (Optional)
	Passcode unlock
	Card swiping unlock (Optional)
	Mechanical key unlock
	Remote unlock

- 
- Please touch the keypad area to activate the lock before opening the door by passcode or card.
 - For your privacy security, it is recommended to change passcodes and clean keypad area regularly in case of remaining marks.
 - Only the [Fingerprint-Card-Passcode-Version](#) supports the fingerprint unlock and card swiping unlock.

- 
- This product has security protection function, fingerprint/passcode/card recognition error number reaches 5 times continuously in 5minutes, the system will be locked forcibly for 3 minutes.
 - The system will be unlocked automatically after 3 minutes.
 - You can turn off this function in EZVIZ app.

1. Fingerprint Unlock



Put your finger on the fingerprint reader, the lock will verify the fingerprint and unlock the door.



2. Passcode Unlock


i The product has protected with Anti-Peeping Passcodes. In case someone is watching you entering a passcode, you can add extra-long digits before or after your original code to make it complex, while still being able to unlock.

- 1 Touch to wake up the keypad.
- 2 Enter the passcode and press ✓.
- 3 The lock will verify the passcode and unlock the door.



3. Card Unlock


- 1 Touch to wake up the keypad.
- 2 Place the recorded proximity card on the card swiping area.
- 3 The lock will be unlocked automatically.



4. Mechanical key Unlock


i Please keep the mechanical key properly for further use.

- 1 Open the cover of the mechanical keyhole.
- 2 Insert the key and rotate it, then push to open the door.




5. Inside Unlock

- Press the "Electronic Button" on the back panel to unlock when the door is locked.



- Rotate the "Secure Knob" on the rear panel to unlock when the door is locked.



Multiple Locking Methods

1. Auto-lock

Once the door is closed, the lock will be automatically locked.



- You can set this function in EZVIZ app.
- This function needs to be used with a Bluetooth door sensor. Please purchase a EZVIZ smart door sensor.

2. Countdown locking

Open the "countdown locking" function in the EZVIZ app. After this function is enabled, the lock will automatically locked after the countdown ends.

3. Outside locking

Press and hold the "√" on the front panel for more than 3 seconds to lock.


4. Inside locking

- Once the door is closed, press the "electronic button" on the rear panel to lock.
- Once the door is closed, rotate the "secure knob" on the rear panel to lock.

Operation and Management

1. Emergency Unlock

When batteries are out of power, connect the emergency power supply interface of the front panel with power bank to charge the lock through Type-C power cable and then unlock the door.



2. Alarms

1. Anti-tamper Alarm

Once being dismantled by force, the lock will send out alarm lasting about one minute.

2. System Locked Alarm

Verify with wrong fingerprint, passcode or card 5 times in a row, the system will be locked for 3 minutes.

3. Low Battery Warning

Once battery voltage is low, the voice prompt will remind you to replace battery.

4. Door is not closed Warning

If the door is not closed properly, the lock will try to lock 3 times, and an alarm will be triggered if it fails.

3. Restore to Factory Settings

1. Remove the battery cover of rear panel and take out batteries.

2. Press the SET button for 5s, meanwhile put back batteries in the battery slot.

3. Release the SET button and press ✓ to confirm after voice prompts.

4. One-time Passcode

When visitors arrive, you can create a one-time door passcode for them.

- The one-time passcode takes effect immediately after generation.
- Once enabled, one-time passcodes can be generated even when the lock is offline.

5. Super Power-saving Mode

Add the Super Power saving mode, which improves battery performance and lasts longer.

Opening method: Enter the battery management option from the Settings page.

6. One-time Mute function

1. Touch the keypad area to wake up the keypad.

2. Press and hold "0" until the keypad flashes twice to indicate the function is on.


- When the one-time mute function is enabled, the door goes into silent mode.
- The lock will automatically exit this mode when it has been unlocked by verification with the added fingerprint, passcode or card from the outside.

Operations on the EZVIZ App

i The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

1. Homepage


When you launch the EZVIZ app and tap your lock, you can view and manage the lock as needed on the homepage.



Parameter	Description
Battery	You can see the battery remaining capacity here.
Signal	You can see the Wi-Fi signal strength of the lock here.
Bluetooth	You can see the Bluetooth connection status.
Unlock	Tap to unlock the lock. i The function is disabled by default. If you want to use it, please go to "settings-Unlocking settings" to enable it.
User Management	You can tap to manage the users here. i After adding a user, you can also add unlocking methods for that user, such as fingerprint, digital passcode, proximity card, and duress passcode. Please note that the unlocking method needs to operate on the lock.
Temporary Passcode	Tap to generate a temporary access code for visitors to open the door.
Bluetooth Key	Tap to share Bluetooth key to your family members or guests.
All Events	Check all events happened to the lock.

2. Settings

In the settings page, you can set the parameters of the device.



Parameter	Description
Name	View or tap to customize the name of your device here.
Unlock Settings	You can enable remote unlock here, set the unlock method and door opening direction, etc.
Battery	Check the battery capacity of the lock.
Message Notification	You can manage the device message and EZVIZ app notification.
Audio Settings	You can set relevant audio parameters for your device.
Door-opening Logs	You can see the door-opening logs here.
Privacy Settings	• Privacy mode: When enabled, the door can only be unlocked with the fingerprint, passcode and proximity card of the administrator, or with the mechanical key. And the lock will mute at the same time. • Trial and error locking: when enabled, the system will be locked for 3 minutes and you cannot use the electronic key to unlock when unlocking errors reached 5 times in 5 minutes.
Network Settings	You can see the Wi-Fi connection status here.
Device Information	You can see the device information here.
Share Device	You can share the device to your family members or guests.
Delete Device	Tap to delete the lock from your EZVIZ account.

Maintenance

1. Daily Maintenance

- Do not put corrosive materials near the lock to avoid lock damage and impacting its gloss.
- If door deforms, it increases friction that combined latch bolt entering the box strike plate and bolt cannot extend fully. At this time, adjusting strike plate position is needed.
- Replace batteries immediately once battery voltage is low to ensure the normal use of the lock. Pay attention to the positive and negative poles of batteries when replacing them.
- When collecting fingerprint, press your finger on the reader horizontally.
- Ask professionals to check the lock if it is not flexible.
- Keep lubricant in the rotating part of the lock to keep it rotate smoothly and prolong its service life.
- It is recommended to check the lock once every six months or one year, and check whether fixed screws are loose.
- Keep the mechanical key properly.

2. FAQ

Problem	Cause	Solution
Door cannot be opened normally by fingerprint, passcode or card verifications.	Lock installation issue	Please have professionals recheck the installation.
	User authority is not within the validity period.	Please use fingerprints, passcodes or cards of other users, or update the user validity period through EZVIZ app.
No response from the fingerprint reader.	Fingerprint reader is damaged.	Please have professionals recheck the installation.
Lock cannot be locked.	The motor is damaged.	Please have professionals recheck the installation.
	Issue with unlocking method setup	Enter the EZVIZ app to set up unlocking method.
Issue with lock tongue popping out.	Installation error	Please have professionals recheck the installation.
The device is often offline.	The lock is not connected to the network.	Please connect the lock to a network with better and more stable signal.
Fast battery power consumption.	Network is unstable	Please change to a stable network signal.
		Please turn off the Wi-Fi switch on EZVIZ app.
Door cannot be opened with mechanical key	Incorrect mechanical key	Use the correct mechanical key
	Lock cylinder is damaged	After opening the door, please have professionals check and replace damaged components.
	The mechanical key cannot be fully inserted	
The door cannot be opened with a one-time passcode.	The lock is offline.	Please connect the lock to the network and try again.
Can't turn off the super power-saving mode on the EZVIZ app	The lock is offline	Please touch the keypad to wake up the device and the lock will automatically connect to the network, then try again.

 For additional information about the device, please refer to www.ezviz.com/eu.

3. Replaceable alkaline dry cells

The battery type of the device: Replaceable alkaline dry cells.
Battery model: LR6
Rated voltage: 1.5 V DC
Rated capacity: 2950mAh
Battery manufacturer: NINGBO GP & SONLUK BATTERY CO., LTD.

Ingredient	Chemical Formula	CAS No.	Approximate Content (wt%)
			LR6
Manganese Dioxide	MnO ₂	1313-13-9	42.6
Zinc	Zn	7440-66-6	18.1
Water	H ₂ O	7732-18-5	8.3
Potassium Hydroxide	KOH	1310-58-3	6.3
Graphite	C	7782-42-5	3.0
Brass	CuZn	12597-71-6	2.4
Iron	Fe	7439-89-6	17.5
Ni-plating	Ni	7440-02-0	0.3
Nylon	(C ₁₂ H ₂₂ N ₂ O ₂) _n	32131-17-2	0.9
Cellulose	(C ₆ H ₁₀ O ₅) _n	65996-61-4	0.3
PVA	(C ₂ H ₄ O) _n	9002-89-5	0.3

4. Information for Private Households

1. Separate collection of waste equipment: Electrical and electronic equipment that has become waste is referred to as waste equipment. Owners of waste equipment must dispose of it separately from unsorted municipal waste. In particular, waste equipment does not belong in household waste, but in special collection and return systems.
2. Batteries and rechargeable batteries as well as lamps: Owners of waste equipment shall, as a rule, separate waste batteries and rechargeable batteries that are not enclosed in the waste equipment, which can be removed from the waste equipment without being destroyed, from the waste equipment before handing them in at a collection point. This does not apply if waste equipment is prepared for reuse with the participation of a public waste management authority.
3. Options for returning waste equipment: Owners of waste equipment from private households can return it free of charge to the collection points of the public waste management authorities or to the take-back points set up by manufacturers or distributors within the meaning of the Electrical and Electronics Equipment Law. Stores with a sales area of at least 400 m² for electrical and electronic equipment and those grocery stores with a total sales area of at least 800 m² that offer electrical and electronic equipment several times a year or on a permanent basis and make it available in the market are required to take it back. This also applies in the case of distribution using means of distance communication, if the storage and shipping areas for electrical and electronic equipment are at least 400 m² or the total storage and shipping areas are at least 800 m². Distributors shall, in principle, ensure take-back by providing suitable return facilities at a reasonable distance from the respective end user. The possibility of returning waste equipment free of charge exists for distributors who are obliged to take it back, among other things, if a new similar device that essentially fulfills the same functions is delivered to an end user.
4. Privacy Notice: Waste equipment often contains sensitive personal data. This applies in particular to devices of information and telecommunications technology such as computers and smartphones. In your own interest, please note that each end user is responsible for deleting the data on the waste equipment to be disposed of.
5. Meaning of the symbol "crossed-out wheelie bin": The symbol of a crossed-out wheelie bin regularly depicted on electrical and electronic equipment indicates that the respective device is to be collected separately from unsorted municipal waste at the end of its service life.