

COPYRIGHT © Hangzhou EZVIZ Software Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as “EZVIZ”). This user manual (hereinafter referred to as “the Manual”) cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.


### **About this Manual**

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the EZVIZ™ website (<http://www.ezviz.com>).

### **Revision Record**

New release – January, 2025

### **Trademarks Acknowledgement**

EZVIZ™, ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

### **Legal Disclaimer**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED “AS IS”, WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

# Table of Contents

<b>Overview .....</b>	<b>1</b>
1. Package Contents .....	1
2. Basics .....	1
<b>Setup.....</b>	<b>2</b>
1. Get the EZVIZ App .....	2
2. Choose an Installation Location.....	3
3. Power on the Device.....	3
4. Connect the Device to Wireless Network .....	4
5. Add the Device to EZVIZ .....	4
<b>One-tap Pairing .....</b>	<b>5</b>
<b>Operations on the EZVIZ App.....</b>	<b>6</b>
1. Homepage.....	6
2. Settings.....	7
<b>INFORMATION FOR PRIVATE HOUSEHOLDS.....</b>	<b>7</b>

Overview

1. Package Contents



Device×1











Regulatory Information×1




Quick Start Guidex1

2. Basics



Name	Description	
LED Indicator		Solid Red: Device is starting up./Device is being restored to factory settings.
		Slow-flashing Red: Network exception.
		Solid Blue: Device is working properly.
		Fast-flashing Blue: Device is searching for and connecting to the uplink network *.
		The wireless network that the device will connect to.
		Flashing alternately in red and blue: WPS (Wi-Fi Protected Setup) pairing / Connecting EZVIZ camera to the wireless network.
		Off: Device is not powered on.

Name	Description
WPS/SYNC Button/ RESET Button	<ul style="list-style-type: none"> <li>• Press once to simultaneously enable WPS pairing and one-tap pairing.</li> <li>• Press and hold for 7 seconds to restart and set all parameters to defaults.</li> </ul> <div>  <ul style="list-style-type: none"> <li>• The one-tap pairing is suspended until the device is connected to the uplink network.</li> <li>• The WPS pairing and one-tap pairing remain active for 120 seconds.</li> </ul> </div>


## Setup


### Follow the steps to set your device:

1. Get the EZVIZ App, and log in to your EZVIZ App account.
2. Choose an installation location.
3. Power on your device.
4. Add the device to your EZVIZ user account.

### 1. Get the EZVIZ App


1. Connect your mobile phone to Wi-Fi (suggested).
2. Download and install the EZVIZ App by searching "EZVIZ" in the App Store or Google Play™.
3. Launch the app and register an EZVIZ user account.



- 
 If you have already used the app, please make sure that it is the latest version. To find out if an update is available, go to the app store and search for EZVIZ.

## 2. Choose an Installation Location

- Place the device in the middle between router and wireless coverage deadzone. The location you choose must be within the range of your router. It is recommended that the device and other devices be separated by no more than one wall to avoid low signal strength.
- Ensure the installation location is far away from strong sources of electromagnetic interference, such as high-voltage power equipment and RF devices.
- The power outlet supplying this device should be as far from the ground as possible and make sure the power outlet is not covered.
- If the network is slow or unstable, try installing the device in a different location or adjusting the antenna to a different angle, and then monitor the network performance.



## 3. Power on the Device

1. Plug the device into a power outlet. When the LED indicator is fast-flashing blue, the device is ready for wireless network connection.
2. Unfold the antennas and keep it vertical to the ground.



## 4. Connect the Device to Wireless Network

You can connect the device to wireless network of your router through the three following methods:

### Connect via WPS Pairing

- This method only works if your router support WPS function.
- After the WPS pairing is completed, the device will have the same Wi-Fi name, password and encryption type as the router. You can modify these parameters in EZVIZ App. For details, please refer to ["Homepage"](#).

Press the WPS button on your router and then press the WPS/SYNC button on this device. This device will automatically connect to the wireless network of your router.

### Connect via EZVIZ App

Please add the device to EZVIZ and select the uplink network. For details, please refer to ["Operations on the EZVIZ App"](#).

### Connect via Web Management Interface

1. Connect your phone to the device's wireless network(name: EZVIZ\_xxxxxx, no password by default).
2. Enter "wifi.ezvizlife.com" or "192.168.8.1" in the browser to access the device's Web management interface.
3. Follow the wizard prompts to complete quick setup: set the login password and select the uplink network.

## 5. Add the Device to EZVIZ

1. Log in to your EZVIZ account.
2. On the Home screen, tap "+" on the upper-right corner to go to the Scan QR Code interface.
3. Scan the QR Code on the cover of the quick start guide or on the body of the device.



4. Follow the EZVIZ App wizard to add the device to your EZVIZ App account.

## One-tap Pairing

After the network configuration is completed, you can connect other EZVIZ devices that support One-tap Pairing to the device's wireless network. Here takes the EZVIZ network camera as an example.

1. Power on the camera and set it to network configuration mode.
2. Short press the WPS/SYNC button on the device, the camera will automatically connect to the wireless network.









# Operations on the EZVIZ App

- i** The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

## 1. Homepage

When you launch the EZVIZ app, the device page will display as shown below. You can select unlink network and set parameters of wireless network here.



Icon	Description
	Settings. Tap the icon to view or change the device settings.
	Range Extender Setting. Tap the icon to select the uplink network.
	Wi-Fi Setting. You can set the Wi-Fi's name, password and encryption type.
	Working Mode. Tap the icon to set the Wi-Fi's working mode: 2.4G Mode, 5G Mode, Dual-band Mode.
	Web Login Password. Tap the icon to set the login password of Web management interface.



## 2. Settings

Parameter	Description
Name	View or tap to customize the name of your device here.
Device Information	You can see the device information here, including the user guide.
Restart Device	Tap to remotely restart the device.
Delete Device	Tap to delete the camera from EZVIZ app.

 For detailed information, please visit [www.ezviz.com/eu](http://www.ezviz.com/eu).

## INFORMATION FOR PRIVATE HOUSEHOLDS

1. Separate collection of waste equipment: Electrical and electronic equipment that has become waste is referred to as waste equipment. Owners of waste equipment must dispose of it separately from unsorted municipal waste. In particular, waste equipment does not belong in household waste, but in special collection and return systems.
2. Batteries and rechargeable batteries as well as lamps: Owners of waste equipment shall, as a rule, separate waste batteries and rechargeable batteries that are not enclosed in the waste equipment, which can be removed from the waste equipment without being destroyed, from the waste equipment before handing them in at a collection point. This does not apply if waste equipment is prepared for reuse with the participation of a public waste management authority.
3. Options for returning waste equipment: Owners of waste equipment from private households can return it free of charge to the collection points of the public waste management authorities or to the take-back points set up by manufacturers or distributors within the meaning of the Electrical and Electronics Equipment Law. Stores with a sales area of at least 400 m<sup>2</sup> for electrical and electronic equipment and those grocery stores with a total sales area of at least 800 m<sup>2</sup> that offer electrical and electronic equipment several times a year or on a permanent basis and make it available in the market are required to take it back. This also applies in the case of distribution using means of distance communication, if the storage and shipping areas for electrical and electronic equipment are at least 400 m<sup>2</sup> or the total storage and shipping areas are at least 800 m<sup>2</sup>. Distributors shall, in principle, ensure take-back by providing suitable return facilities at a reasonable distance from the respective end user. The possibility of returning waste equipment free of charge exists for distributors who are obliged to take it back, among other things, if a new similar device that essentially fulfills the same functions is delivered to an end user.
4. Privacy Notice: Waste equipment often contains sensitive personal data. This applies in particular to devices of information and telecommunications technology such as computers and smartphones. In your own interest, please note that each end user is responsible for deleting the data on the waste equipment to be disposed of.
5. Meaning of the symbol “crossed-out wheelie bin”: The symbol of a crossed-out wheelie bin regularly depicted on electrical and electronic equipment indicates that the respective device is to be collected separately from unsorted municipal waste at the end of its service life.