COPYRIGHT @ Hangzhou EZVIZ Software Co., Ltd. ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Hangzhou EZVIZ Software Co., Ltd. (hereinafter referred to as "EZVIZ"). This user manual (hereinafter referred to as "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of EZVIZ. Unless otherwise stipulated, EZVIZ does not make any warranties, guarantees or representations, express or implied, regarding to the

About this Manual

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the $\blacksquare Z \lor IZ^{\intercal}$ website (http://www.ezviz.com).

Revision Record

New release - January, 2022

Trademarks Acknowledgement

EZVIZ ™, 😽 ™, and other EZVIZ's trademarks and logos are the properties of EZVIZ in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS", WITH ALL FAULTS AND ERRORS, AND EZVIZ MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL EZVIZ, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF EZVIZ HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL EZVIZ'S TOTAL LIABILITY FOR ALL DAMAGES EXCEED THE ORIGINAL PURCHASE PRICE OF THE PRODUCT.

EZVIZ DOES NOT UNDERTAKE ANY LIABILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE AS THE RESULT OF PRODUCT INTERRUPTION OR SERVICE TERMINATION CAUSED BY: A) IMPROPER INSTALLATION OR USAGE OTHER THAN AS REQUESTED; B) THE PROTECTION OF NATIONAL OR PUBLIC INTERESTS; C) FORCE MAJEURE; D) YOURSELF OR THE THIRD PARTY, INCLUDING WITHOUT LIMITATION, USING ANY THIRD PARTY'S PRODUCTS, SOFTWARE, APPLICATIONS, AND AMONG OTHERS.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. EZVIZ SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, EZVIZ WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. SURVEILLANCE LAWS AND DATA PROTECTION LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. EZVIZ SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THE ABOVE AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Table of Contents

Overview	1
1. Package Contents	1
2. Basics	1
Setup	2
1. Get the EZVIZ App	
2. Power on Temperature & Humidity Monitor	2
3. Add Temperature & Humidity Monitor	
Installation	4
Specifications	5
Operations on the EZVIZ App	5
1. Homepage	5
2 Cottings	

Overview

1. Package Contents



Temperature & Humidity Monitor (x1)







Regulatory Information (x1)

Quick Start Guide (x1)

2. Basics

Temperature & Humidity Monitor detects and displays the indoors temperature and humidity and then sends the related data to the linked EZVIZ gateway. After adding the Monitor to EZVIZ APP, you can view the related data on your phone in real time; moreover, it can trigger other EZVIZ smart products to provide you a smart home life

Structure



Interior Diagram

Name	Description
Button	• Press and hold the Button for 5s, the Temperature & Humidity Monitor will restart and then enter device adding mode; at the same time, the signal icon on the device screen will flashes quickly. • Short press the Button to switch data display between degree centigrade ($^{\circ}\!$

Display Screen



Setup

Follow the steps to set your monitor:

- 1. Get the EZVIZ app.
- 2. Power on your Temperature & Humidity Monitor.
- 3. Add the Monitor to your EZVIZ account.

1. Get the EZVIZ App

- 1. Connect your mobile phone to Wi-Fi (suggested).
- Download and install the EZVIZ app by searching for "EZVIZ" in the App Store or Google Play™.
- 3. Launch the app and register an EZVIZ user account.



If you have already used the app, please make sure that it is the latest version. To find out if an update is available, go to the app store and search for "EZVIZ".

2. Power on Temperature & Humidity Monitor

Step 1 Remove Rear Cover

Remove the rear cover of the Temperature & Humidity Monitor by rotating it anticlockwise as shown in the figure below.



It is recommended to put the Temperature & Humidity Monitor on your hands to press and twist it by your palm.

Step 2 Remove Insulation Strip

Draw out the battery insulation strip with your hand.



- Please replace the battery in time when low power prompts on your phone.
 - If you need to replace the battery, please purchase one CR2450.
 - · When replacing batteries, please insert with the positive side facing up.

3. Add Temperature & Humidity Monitor

The Monitor should be used along with EZVIZ Zigbee Smart Gateway (afterinafter referred to as "gateway"). Please add gateway to the EZVIZ Cloud by referring to the gateway user manual, and then add the Monitor to the gateway by following the below steps.

Method One: Add by Scanning QR Code

- 1. Log in to your account through EZVIZ app, tap the device adding icon and then the QR code scanning interface will be displayed.
- 2. Press and hold the Button of the Monitor for over 5s till the signal icon on Monitor screen flashes, and then the Monitor enters device adding mode.



- 1 The Monitor will exit device adding mode automatically over 3 minutes.
- 3. Scan the QR code on the inner side of the cover or the cover of the user manual, and then add the Temperature & Humidity Monitor to the gateway.



- $5.\ \mbox{Add}$ the Temperature & Humidity Monitor to the gateway by following the wizard on the app.
- 6. Rotate tightly the rear cover of the Temperature & Humidity Monitor clockwise till the aligning mark ▶ on rear cover is aligned with the mark ⊕ on the front cover.




Method Two: Add by the Gateway

- When adding Temperature & Humidity Monitor by the gateway, place the Monitor as close to the gateway as possible.
- 1. Press the Funtion Button of the gateway to make the gateway enter device adding mode.



2. Press and hold the Button of the Monitor for over 5s till the signal icon on Monitor screen flashes, and then the Monitor enters device adding mode.



- The Monitor has been added to the gateway successfully and the gateway prompts adding successfully.
- 5. After the Temperature & Humidity Monitor is added successfully, rotate the Monitor rear cover clockwise to tighten the rear cover till the aligning mark ▶ on rear cover is aligned with the mark ⊕ on the front cover.



Installation



- Metal will cause ZigBee signal attenuation, so please do not install the Monitor on a metal door, it
 is recommended to install it on the wall next to the door.
- · Do not install the Monitor in an environment with corrosivity or intense magnetic fields.
- It is recommended that the distance between the Monitor and gateway be less than 20m. If there
 are walls between them, the number of walls should be no more than 2.
- It is recommended to use the Monitor in a house with an area of no more than 200 square meters; if your house is too large, please purchase two or more Monitors for a better using experience.
- Before sticking 3M tape, please swipe the dust on the installation surface to enhance the tape stickiness; do not stick it on a lime wall.

Please place the Monitor on desktop as you needed, or you can stick it on the wall below 1 meter with 3M tape.

Place on the desktop



Stick on the place you needed (with 3M tape)



Specifications

Working Temperature	-10℃ ~ 60℃
Working Humidity	0%~99%RH
Wireless Protocol	ZigBee 3.0
Battery Type	CR2450
Battery Duration	12 months

i For additional information about the device, please refer to www.ezviz/eu.

Operations on the EZVIZ App

1 The app interface may be different due to version update, and the interface of the app you installed on your phone shall prevail.

1. Homepage

Launch the EZVIZ app, open the homepage of the related gateway, you can manage your Temperature & Humidity Monitor as needed on the page.

Log	Detection log of the Monitor.
-----	-------------------------------

2. Settings

Parameter	Description
Device Name	Customize the name of your device.
Temperature/	When enabled, the device will send an alarm message to notice you that the temperature or humidity exceeds the set
Humidity Alarm	values.
Temperature unit	You can check the current temperature unit of the Monitor.
Performance Mode	You can check the current performance mode of the Monitor.
Related Devices	You can see the gateway connected to your monitor.
Device Information	You can see the device information here.
Share	Share your device.
Delete Device	Tap to delete the Monitor from EZVIZ cloud.